

V Shape Sectional Covers

Instructions & Care



WARNING

Fabric is NOT fire resistant. Keep away from open flames or burning logs.


CAUTION

- . Follow your owner's guide for storing and covering your equipment/appliance.
- . When covering an outdoor appliance, let it cool before you put the cover on it.
- . Do not expose the cover to petroleum based cleaning products, they can damage the PVC backing.
- . Remove all cushions to avoid possible mildew before covering your furniture.
- . This product is not intended for use on furniture made of concrete.


Folding Instructions




- 1** Lift cover away from furniture at all corners and lay loosely on top.




- 2** Move to the left end of the cover and locate the two handles at the end of your cover near the orange guide arrow labels and grasp one handle in each hand.




3 Lift the cover, bringing the handles together towards the center and straighten the center fold.




4A While holding the cover in the lifted position, hold both handles in one hand and straighten out the corner (where the two white stitch lines come together).




4B Sweep the bottom hem of the cover towards the front of the sectional to lay the cover flat.




5 Lay the cover flat with the handles the back of the sectional. The Classic Accessories logo will be showing at the front when finished. The left end of the cover should look similar to the illustration when laid flat. Straighten and align the edges.




6 Move to the right side and bring the handles together. Then pull the corner out, and connect rip-n-grip strips. Sweep the bottom hem toward the front of the sectional and lay the end flat with the handles hanging toward the back of the sectional.





7 Locate the center pair of handles and bring rip-n-grip strips together. It is important to ensure that all the handles in this section are paired together and are pulled toward the back with the folded layers lying flat.




8 Move to the remaining end of the cover and locate the two handles at the end of the cover near the orange guide arrow labels and grasp one handle in each hand. Lift and bring the loop handles together, then transfer both handles to one hand. Straighten the center fold. (The same as in step 3 and 4)




9 Walk the remaining end of the cover around to the back corner of the sectional to align with the other side and to form a long rectangle. Straighten and smooth out all layers.




10 Locate the orange stitch line (L). Fold the right end to lay over the left end at the orange stitch line.




11 Straighten and align top, bottom, and interior layers to eliminate bunching.




12 If you prefer, transfer to a flat surface, making sure both top, bottom, and interior layers are laying flat.



13 Fold both ends in toward the center.




14 Continue folding the ends in toward the center to desired length.




15 This illustration shows an example of a completely folded cover. (Yours will look different if you choose to fold it more or less times than we did.)


Flat surface folding instructions




1A Spread your cover out on the ground or other flat surface. Starting at end (A) end of the cover, grasp one handle in each hand, lift up, and bring the handles together.




1B Straighten the center fold. (Fig Z). Lay end back down with handles together and facing toward the back. Smooth and align layers. This will be repeated for all sets of handles starting with (A) and finishing with (B) (Fig. Y).




2 Finish with the two handles at the end (B) of the cover and lay flat like the others. Bring end (B) around to extend the top panel to its full length.




3 Connect rip-n-grips together. Ensure all layers are lying flat.



4 Locate the orange stitch line and fold end (B) over end (A) at the orange stitch line.



5 Straighten out fabric panels and align all edges. Fold the ends toward the center to create a rectangle.



6 From this point, continuing folding ends in until you reach desired length.

CLEANING AND CARE: Hand wash with lukewarm water. DO NOT USE SOAP, DETERGENT OR BLEACH as it may remove the protective coatings added by the factory. Do not pack wet. Air dry.

Never store a wet cover in a confined area as the cover can be damaged by mildew.

