
Copyright @ 2026 Vego

Gardening
Made Easier.
Anytime,
Anywhere.

User Manual for Flower Cage Trumpet 2-Pack (L)

Models: VPSSFCTLDG-2

Gardening Made Easier. Anytime, Anywhere.




Contact Us

+1 (866) 597-1888
Vego Garden Academy
hello@vegogarden.com
vegogarden.com
vego_garden
Houston, TX

vegogarden.com

Parts List



P1

Qty: 10



P2

Qty: 10




P3
Ø16"
Qty: 2



P4
Ø18"
Qty: 2



P5
Ø24"
Qty: 2



F1
M4x12
Qty: 30



F2
M4
Qty: 30



T1

Qty: 1

Safety Precautions

This product may contain sharp metal corners and edges. To prevent injury:

- Handle with care at all times
- Wear gloves, closed-toe shoes & long pants when handling
- Work on a stable, clean surface away from children and pets
- Follow all instructions carefully and use tools only as directed

If you are unsure about any step, pause and seek assistance.




Assembly Guide


1 Assemble the Support Rings

Assemble the rings from the bottom to the top as shown in the diagram.
Use F1 screws and F2 nuts to connect P2 rods with P3 (small ring), P4 (medium ring) and P5 (large ring) in sequence.

⚠ Important:

When installing P3 and P4, do not fully tighten the screws, tighten each screw about 3–4 turns only.
The flattened connection points on P4 and P5 have a slight angle.
Ensure the rings are installed in the correct top and bottom orientation during assembly.
After P5 (the largest) is installed and everything is properly aligned, use T1 and a screwdriver to fully tighten all screws.






2 Attach the Ground Stakes

Thread the P1 ground stakes onto the P2 vertical support rods, one by one, and tighten securely, then turn the support upright and place it into the soil.

Note: Make sure all rods are evenly tightened and standing straight.



Important

For your safety, please ensure the product is securely fastened. In windy areas, be sure to anchor your Flower Supports firmly to the ground.

Maintenance and Care

- Clean with a soft cloth , use mild soap and water if needed.
- Do not use abrasive cleaners or harsh chemicals.
- Avoid prolonged contact with standing water or constantly wet soil.
- If the surface coating is scratched, touch up promptly with rust-resistant outdoor metal paint.
- Periodically check and retighten fasteners as needed.

Warranty

Warranty: 3 Years Structural Guarantee

Exclusions: Damage caused by misuse, improper installation, or modifications is not covered.

vegogarden.com