


Christmas Tree Installtion Instruction



Note.

1. Be careful not to pinch any of the light wires (if applicable) between the hinge when shaping the branches.
2. Make sure all bolts are tightly screwed in to keep the tree stable
3. When not in use, store neatly in a cool, dry location protected from sunlight.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.