

## Installation/Instructions for Use

Welcome to purchase our products, thank you for your purchase and support. To ensure the clock works properly, please read the instructions and precautions.



- (1) insert 1 AA carbon-zinc battery into the battery compartment on the back of the clock. Do not use alkaline batteries, as they have too high a current output and can affect the accuracy and lifespan of the clock movement.
- (2) Set the time by turning the rotary button on the back of the movement (rotate clockwise to adjust the time).
- (3) Sometimes wall clocks stop working due to malfunctions during the logistics and transportation process. Please don't worry. For wall clock malfunctions, please refer to the following related methods.

### Fault problems and solutions

1. The pointer does not move, possible reasons: (1) The battery is dead (Solution: Replace with a new battery) (2) The positive and negative terminals of the battery are installed in reverse (Solution: Adjust the direction of the positive and negative terminals of the battery)

2. When the pointer stops, the movement gear does not work:

Possible reasons: (1) The battery is not suitable or the power is insufficient (Solution: Replace with a new AA carbon battery) (2) The second hand is pressed too tightly (Solution: Remove the second hand and reinstall it) (3) The hands are stuck together or rubbing against each other (Solution: Adjust the hands until they are parallel and not touching) (4) The hands are deformed or loose (Solution: You can adjust the hands according to the picture below)



Don't worry about other issues! Please feel free to contact us, and we will solve the problem for you as soon as possible. Wish you a happy life!