




TOOLS REQUIRED



Screwdriver
(Not included)




Allen Wrench



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.





VANITY SET






- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1	2	3	4	5
				
Vanity table (L/R) 2pcs	Legs 8pcs	Glass 1pc	Mirror 1pc	Mirror Support Rail 2pcs






HARDWARE

A	B	C	D
			
Bolt 5/16"x3" 8pcs	Lock washer 5/16" 8pcs	Flat washer 5/16" 8pcs	Allen wrench (M4) 1pc
E	**F**	**G**	**H**
			
Bolt 1/4"x1-5/8" 12pcs	Lock washer 1/4" 12pcs	Flat washer 1/4" 12pcs	Allen wrench (M4) 1pc
J	**K**	**L**	
			
Anti Tip Kit 1 set	Glass holder 4 pcs	Plastic button 8pcs	

Exploded View



are packed in 2 cases


Carton	Disignation	Part		Hardware
	Vanity table (L & R) (2pcs)	1		 A x 8pcs  B x 8pcs  C x 8pcs  L x 8pcs  D x 1pc  K x 4pcs  J x 1set
	Legs (8pcs)	2		
	Glass	3		
	Vanity mirror	4		 E x 12pcs  F x 12pcs  G x 12pcs  H x 1pc
	Mirror Support Rail (2pcs)	5		

ASSEMBLY INSTRUCTIONS

1

Part (1) x2pcs
Part (2) x8pcs
Hardware (A) x8pcs
Hardware (B) x8pcs
Hardware (C) x8pcs
Hardware (L) x8pcs
Hardware (D) x1pc


Attach the Legs (2) to the Vanity table (1L/1R). Secure using Bolt (A) Lock washer (B) Flat washer (C) and Plastic button (L)



2

Part (4) x1pc
Part (5) x2pcs
Hardware (E) x12pcs
Hardware (F) x12pcs
Hardware (G) x12pcs
Hardware (H) x1pc


Align Mirror support rails (5) to Vanity table (1L/1R) ,lift the Mirror support rails (5) and align to the Vanity mirror (4). Secure using Bolt (E) Lock washer (F) Flat washer (G)



ASSEMBLY INSTRUCTIONS


3

Part (3) x1pc
Hardware (K) x4pcs



4

Hardware (J) x1set



Your Touch is the switch

Touch 1 - Night Light
Touch 2 - Energy saver Light
Touch 3 - Bright reading Light
Touch 4 - off

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.


Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.


ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.





CHECK BEFORE PROCEEDING

Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1.If unsure of the proper size, always choose a larger screw and wall anchor.






2. Match the drill bit to the wall anchor and hole size.

3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.






4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.


MAINTENANCE

Yearly Check

We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.

TOOLS REQUIRED






Allen Wrench



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


STOOL






PARTS

1



Seat
1pc

2



Legs
4pcs

HARDWARE

A



Bolt 5/16"x2"
8pcs

B



Lock washer 5/16"
8pcs

C



Flat washer 5/16"
8pcs

D




Allen wrench (M4)
1pc

ASSEMBLY INSTRUCTIONS


1

Part (1) x1pc
Part (2) x4pcs
Hardware (A) x8pcs
Hardware (B) x8pcs
Hardware (C) x8pcs
Hardware (D) x1pc

Attach the Legs (2) to the Seat (1). Secure using Bolt (A) with Lock washer (B) with Flat washer (C)



2



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.