

12'x12'

HARDTOP GAZEBO WITH WOOD POST

ASSEMBLY INSTRUCTIONS



Note: The gazebo needs to be installed in cooperation with four people. The following tools are not included and needed for assembly:



Questions? Issues? Missing Part? Professional Installation Service?

Contact us at email customer.care@sunjooygroup.com


Important Safety Instructions

Warning! To reduce the risk of serious injury, read the following safety instructions before assembling and using the gazebo.

Caution! Always keep children under close supervision while they are using or around this product. Never leave children unattended.

- This product is intended for outdoor use only.
- The product should be assembled on a flat stable surface.
- Do not assemble the gazebo on unstable surfaces.
- Ensure the location and clearance of your gazebo is acceptable.
- The gazebo must be anchored with stakes into the ground for added safety. It is recommended that it should not be permanently attached to a concrete floor or platform.
- Arrange the necessary manpower when assembling or moving the product.
- Some parts may contain sharp edges. Wear protective gloves and glasses if necessary.
- Keep children and pets away while setting up the gazebo.
- Check all nuts and bolts periodically for tightness. When required, tighten them again.
- Repairing and replacing parts should be done by a qualified technician.
- The gazebo is intended for decorative and shade purposes only, and is not designed to withstand harsh weather, including high winds, rain and snow.
- If the product is not being used for long periods of time (e.g. winter), it should be stored in a clean, dry environment.
- Do not put a Liquid Propane or Wood Burning fire pit or fireplace inside the product.
- Do not climb or place heavy objects onto the gazebo roof.
- Retain the original packaging to store and protect the gazebo during the winter months.
- Do not use or enter the gazebo if the following conditions exists:
 - 1. Visible movement of supports, roofing panels or a sagging roof.
 - 2. Unusual noise from the gazebo.
 - 3. Deformed roof panels.
 - 4. Damaged or missing bolts/fasteners.
- Please check your HOA, Local, and State Governments prior to purchasing and assembling gazebos. These local organizations may require permits and specific requirements for installation.
- Maintain your instruction manual for future reference
- Warranty: Please retain you receipt for proof of purchase.

EXPLODED DRAWING



Part List

Description	Label	Part Number	Qty	Part Image
Post	А	P00020022702	4	•
Left Cross Beam	В	P00040148201	4	• •
Right Cross Beam	С	P00040148301	4	•••
Brace 1	D	P00500020003	4	······································
Brace 2	Е	P00500020103	4	\(\cdot\cdot\cdot\cdot\cdot\cdot\cdot\cdot
Support Beam 1	F	P00500074901	4	
Support Beam 2	G	P00500075001	4	·
Base Cover	J	P00610027501	4	
Post Base	К	P00010051301	4	
Cross Beam Inner Baffle	L1	P00220042701	4	
Cross Beam Decoration	L2	P00560027801	4	
Rafter Connector	L3	P00050190501	4	
Middle Decoration	M1	P00560051201	4	
Big Support Beam Supportor 1	M2	P00500074301	4	
Big Support Beam Supportor 2	M3	P00500074401	4	
Middle Support Beam Supportor 1	M4	P00500074501	4	A
Middle Support Beam Supportor 2	M5	P00500074601	4	

Small Support Beam Supportor 1	M6	P00500074701	4	
Small Support Beam Supportor 2	M7	P00500074801	4	
Big Roof Frame	N	P00050190601	4	
Small Roof Decoration	P1	P00560051301	4	
Small Roof Corner Decoration	P2	P00560051401	4	
Middle Beam Connector	P3	P00050190701	4	
Rafter	Q1	P00060258201	4	
Middle Beam	Q2	P00060258301	4	
Small Roof Rafter	Q3	P00060258601	4	
Small Beam 1	R1	P00060258401	4	
Small Beam 2	R2	P00060258501	4	
Small Roof Panel Flashing	R3	P00060258701	4	
Small Roof Connector	S	P00050190801	1	
Hook	Т	P00090019801	1	
Small Roof Panel	U1	P00070125101	4	
Big Roof Small Panel 1	U2	P00070125201	4	
Big Roof Small Panel 2	U3	P00070125301	4	


Big Roof Middle Panel 1	U4	P00070125401	4	
Big Roof Middle Panel 2	U5	P00070125501	4	
Big Roof Big Panel 1	U6	P00070125601	4	
Big Roof Big Panel 2	U7	P00070125701	4	
Small Roof Cap	V1	P00080044301	4	
Top Cover	V2	P00090019801	1	
Rafter Cap	V3	P00080044401	4	
Middle Beam Cap	V4	P00080044501	4	
Rafter Decoration	W	P00560051501	4	


Hardware Pack


Label	Description	Part Number	Qty	Part Image
H1	Bolt M6*20	H100010047	88+5	
H2	Bolt M6*55	H100010063	4+1	
H4	Screw ST4.8*25	H030050052	152+8	
H5	Screw ST4.8*30	H030050058	24+2	
H6	Screw ST8*35	H030030013	32+2	
H7	Screw ST9.5*80	H030010031	8+1	O Baranananana
H8	Bolt M6*45	H100010166	36+2	
H9	Bolt M10*185	H100010165	8+1	
H10	Bolt M8*30	H100040020	16+1	
H11	Flat washer M8	H050080007	32+2	
H12	Flat washer M10	H050080008	16+1	
H13	Nut M10	H040050026	8+1	
H14	T-Nut M8*8	H040090004	16+1	


H15	Bolt M6*30	H100010170	8+1	
H16	Flat washer M6	H050030001	24+2	
H17	Nut M6	H040070002	16+1	
НН	M6 Rubber Washer	H050050018	16+1	
HS	Stake Φ8*180	H070010003	8	
HW1	Wrench M6	H090010017	2	
HW2	Allen Key M8	H090030005	1	
HW3	Wrench M10	H090010015	2	






















































































































































Secure the assembled gazebo to the lawn with the stakes (HS).



Cleaning and Maintenance

Caution!

- Check all screws and nuts periodically for tightness, fastening them again as required.
- Disassemble the gazebo in the reverse order of the assembly steps. Always disassemble the gazebo completely. A partially disassembled gazebo is not stable enough to resist wind and bad weather, and therefore can be damaged and/or cause damage.
- Clean the gazebo with mild soap and water. Rinse thoroughly, and wait until the product is dry before reassembling it.
- Remove all excess snow from the roof.
- Do not use bleach, acid, or other abrasive cleaners on the frame parts.
- Steel components for this gazebo are treated with rust inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty, To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting paint (not included). Surface rust can also be easily removed with a very light application of regular cooking oil or WD-40. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping onto deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.