

2 lights Semi-Flush Mounts

NOTE: ALWAYS TURN POWER OFF BEFORE INSTALLING LIGHTING FIXTURES!

■ Specification

Voltage: 110-130V
 Material: Metal
 Color: Black
 Lamp holder: E26
 Bulb info: MAX 60W TYPE-A19
 Fixtures Dimensions: 16in/405mm(D)*10.25in/260mm(H)
 Installation Dimensions: 10.25in/260mm(H)
 Wire Length: 8in/200mm
 Usage: Indoor use only


■ Easy Installation

1. Put the breach of Lamp Shade Washers Slip over the Nipple of the Fixture , and lock the Lamp Shade tightly with the Fixture Nut.
2. Adjust the arm Angle so that the arm is in the correct position.
3. Screw the **Mounting Screws** into the **Crossbar**, place the **Lock Washers** over the **Mounting Screws** and thread the **Hex Nuts** onto the **Mounting Screws** as shown. Secure the position of the **Mounting Screws** by tightening the **Hex Nuts** against the **Crossbar**.
4. Secure the **Crossbar** to the **Outlet Box** with **Outlet Box Screws** (Non inclus).
5. Using wire connectors not supplied connect the **House Ground Wire** to the **Fixture Ground Wire** connect the **House White Wire** to the **Fixture Supply Wire** White or **Ribbed Side** connect the connection with approved electrical tape.
6. Place the **Ceiling Canopy** onto **Outlet Box** aligning 2 holes in the **Ceiling Canopy** with 2 **Mounting screws** threaded on the **Crossbar** and secure it against wall with **Mounting Balls**.
7. Install Bulb (Non inclus).


* **Install correct bulbs referring to fixture markings and or labels for maximum wattage. Your installation is completed now Restore electricity Retain this sheet for future reference.**

■ Package Include

1 x Fixture	1 x Crossbar with Screws
2 x Mounting Balls	1x Lamp Shade
1 x User Manual	



Wiring Installation



Fixture Installation