


INSTRUCTION MANUAL

MANUEL D'INSTRUCTIONS

The letter [b] stands for 01–10, [c] stands for color and [h] stands for 1", 1.5", 2", 2.5", 3", 3.5", 4".


La lettre [b] signifie 01–10, [c] signifie couleur, et [h] signifie 1 po, 1.5 po, 2 po, 2.5 po, 3 po, 3.5 po, 4 po.




Mattress Topper

Couvre-matelas

1



2 Remove outer plastic.



⚠ Be careful not to cut topper material.


3

Unroll mattress topper.




4

Remove the remaining plastic.




5

Material should fully expand after 48 hours.




6

Your mattress topper is now ready!

**ATTENTION:**

1. Due to the unique properties of memory foam, dimensions may subtly VARY after full expansion. It is normal and WILL NOT affect the performance of your topper.
2. Material may initially have a slight odor that will dissipate with time and air circulation. Please air out the mattress topper for 72 hours to allow the material to expand and smell to dissipate.
3. Discoloration to memory foam may appear over time due to oxidization. Oxidization is a natural process when memory foam is exposed to light; it will not affect the performance of your mattress topper.

1



AVERTISSEMENT



2

Retirer le plastique extérieur.



⚠ Faites attention de ne pas couper le matériel du surmatelas.


3

Dérouler le surmatelas.



4


Retirer le plastique restant.



5


Le matériau doit se dilater complètement après 48 heures.

48 heures



6

Votre surmatelas est maintenant prêt !



ATTENTION :

1. En raison des propriétés uniques de la mousse à mémoire de forme, les dimensions peuvent légèrement VARIER après une expansion complète. c'est normal et n'affectera PAS les performances de votre surmatelas.

2. Le matériau peut initialement avoir une légère odeur qui se dissipera avec le temps et la circulation de l'air. Veuillez aérer le surmatelas pendant 72 heures pour permettre au matériau de se dilater et aux odeurs de se dissiper.

3. Une décoloration de la mousse à mémoire de forme peut apparaître avec le temps en raison de l'oxydation. L'oxydation est un processus naturel lorsque la mousse à mémoire de forme est exposée à la lumière ; cela n'affectera pas les performances de votre surmatelas.