


Assembly Instructions



3pc Steel Chat Set

Questions, problems, or missing parts?
Before returning to the store, call Customer Service.

Retain this manual for future use.


Chair Parts & Tools

PART	QTY	PICTURE & DESCRIPTION	PART	QTY	PICTURE & DESCRIPTION
A	2	 Chair Frame	AA	8	 M6X15 Bolt
B	2	 Left Leg	BB	8	 M6 Flat Washer
C	2	 Right Leg	CC	1	 Allen Wrench
D	2	 Seat Cushion			
E	2	 Lumbar Pillow			
			WARNING: To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.		

Chair Assembly

Step 1:

- Place the chair frame (A) on a soft surface. Line up the bolt holes on the chair frame (A) and left leg (B). Insert M6x15 bolt (AA) through M6 flat washer (BB).
- Tighten using the Allen wrench (CC).
- Repeat the same steps for the right leg (C).



Step 2:

- Ensure all connections are secure.
- Turn the chair right side up.
- Place seat cushion (D) and lumbar pillow (E) on the chair as shown.




Table Parts & Tools



PART	QTY	PICTURE & DESCRIPTION	PART	QTY	PICTURE & DESCRIPTION
F	1	 Table Rim	AA	8	 M6X15 Bolt
G	2	 Table Leg	BB	8	 M6 Flat Washer
H	1	 Glass			
			WARNING: To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.		

Table Assembly


Step 1:

- Place the table rim (F) on a soft surface. Insert the table legs (G) to table rim (F) as shown.
- Repeat the above step until both table legs (G) are secure to the table rim (F).



Step 2:

- Ensure all connections are secure.
- Turn the table right side up.
- Gently place the glass (H) onto the table rim (F).



Outdoor Furniture



IMPORTANT

If you have any problems with this product (missing or damaged parts, assembly issues, etc.),

PLEASE DO NOT RETURN TO THE RETAILER/STORE

from where you purchased the product.

To expedite any future warranty claims, please retain the instruction sheet, warranty card and receipt for future use.

Care and Maintenance

Store furniture in an upright position. Be careful to never allow water to build up in the frames as this will cause corrosion and freeze damage in cold climates. Wash all frames with a solution of mild soap and water. Rinse with clean water and dry with a soft absorbent cloth towel. Frames can be treated with a liquid wax for maximum protection against UV rays and/or salty, damp air. If your set includes cushions, slings, and/or an umbrella they may be cleaned by hand with a solution of soap and water with a clean water rinse. (Never machine wash cushions, slings or umbrella covers as this will result in shrinkage or damage). After cleaning cushions tip on end and allow to drip dry. (Never use a commercial or home dryer to tumble dry fabric goods). Do not use bleach or solvents to clean any product! This will void the warranty.