











Attention


1. Thank you for your support. Table is packaged individually, 2 chairs in one package and 4 chairs in one package. So the number of packages you will receive depends on the products you purchased. If you purchased 6-piece dining set, there will be 3 packages which may arrive at different times, please be patient!
2. All bolts should be hand tightened securely before use. Never use power tools or excessive force during assembling and tightening of bolts
3. If there is any damage, please send us clear photos of the damaged parts as attachments. We will check and offer you the best solution soon. If there are any missing items or other issues, please feel free to contact our customer service team for assistance.

Parts List

A X4  Back	B X4  Seat	C X4  Left Leg	D X4  Right Leg	E X40  M6x20 Bolt
F X8  M6x45 Bolt	G X48  Washer	H X48  End Cap	I X1  Allen Key	J X8  Rubber washer


Assembly Guide

STEP 1




Connect Back (A) with Left Leg (C) and Right Leg (D) using Bolt (F), Washer (G), End Cap (H) and Rubber washer (J) as shown in diagram.

STEP 2



Connect Seat (B) with the rear legs on (A) using Bolt (E), Washer (G) and End Cap (H) as shown in diagram.

STEP 3



Connect Seat (B) with front legs on (C&D) using Bolt (E), Washer (G) and End Cap (H) as shown in diagram.