

# VICTORIA WOODEN DOLL HOUSE (WDH03)

## Assembly Instruction

(Assembled by adult)



49.1WDH03.150

\*Please follow this instruction to avoid assembly errors.  
\*For customer service, please contact **E-mail: shop@robud.com**

### ⚠ WARNING:

The product is not suitable for children under 36 months. Children should use the product under adult's guidance.  
The product includes small parts which may cause children of 36 months or younger to swallow by mistake.  
After opening the package, please keep the packaging items such as plastic film away from babies and children to prevent choking hazard.

x1	x1	x1	x1	x1	x1	x1	x1
x1	x1	x1	x1	x1	x1	x1	x1
x1	x1	x1	x1	M4X30mm X36	M4X15mm X5	M6x10mm x2	
x1	x1	x1	x1	x1	x1	x2	x1
x2	x1	x1	x1	x1	x1	x1	x1
x1	x1	x1	x1	x1	x1	x1	

**1**

**2**

**3**

**4**

**5**

**6**

