


ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

Dining Table



ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261




ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261


Part List

(A)




TOP TABLE (1pc)

(B)




SIDE PANEL LEFT (1 pc)

(C)




SIDE PANEL RIGHT (1 pc)

(D)




BACK PANEL (1pc)

(E)




BETWEEN PANEL (1pc)

(F)



BOTTOM PANEL (1 pc)

(G)



TOP PANEL (1pc)

(H)



RIGHT FRONT LEG (1pc)

ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

Part List

I



LEFT FRONT LEG (1pc)

J




RIGHT REAR LEG (1pc)

K




LEFT REAR LEG (1pc)

L



SHORT STRETCHER (1pc)

M




LONG STRETCHER (1pc)

ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

Hardware List


①



Ø 5/16" x 35 mm

BOLT (8 pcs)


②



Ø 1/4" x 50 mm

BOLT (8 pcs)


③



Ø 5/16" x 70 mm

BOLT (8 pcs)


④



Ø5/16" x 13 mm

LOCK WASHER (24 pcs)


⑤



Ø5/16" x 19 x 2 mm

FLAT WASHER (8 pcs)

⑥



4 mm


ALLEN KEY (1 pc)

ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

Hardware List


7



Ø4 x 25mm

WOOD SCREWS (3 pcs)


8



Ø4 x 38mm

WOOD SCREWS (2 pcs)


9



Ø3.5 x 12mm

WOOD SCREWS (4pcs)


10



13 x 17 x 29 mm

PATCH V (4 pcs)

11



Ø10*12mm

CROSS NUT(8 pcs)


12



Ø10 x 30 mm

WOOD DOWEL (2 pcs)

Tools Requires





NOT INCLUDED

ASSEMBLY INSTRUCTIONS


ITEM NO.N711P515261

STEP 1:



BOLT Ø 1/4" x 50 mm	LOCK WASHER Ø5/16" x 13 mm	ALLEN KEY 4 mm	CROSS NUT Ø10x12mm	PATCH V 13 x 17 x 29 mm	WOOD SCREWS Ø3.5 x 12 mm
					
② x 8	④ x 8	⑥ x 1	⑪ x 8	⑩ x 4	⑨ x 4

STEP 2:




WOOD SCREWS Ø4 x 25 mm

⑦ x 3

ASSEMBLY INSTRUCTIONS


ITEM NO.N711P515261


STEP 3:



BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø 5/16" x 70 mm	Ø5/16" x 13 mm	Ø5/16" x 19 x 2 mm	4 mm
			
③ x 8	④ x 8	⑤ x 8	⑥ x 1

STEP 4:




BOLT	LOCK WASHER	ALLEN KEY
Ø 5/16" x 35 mm	Ø5/16" x 13 mm	4 mm
		
① x 6	④ x 6	⑥ x 1


ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

STEP 5:




STEP 6:



ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515261

STEP 7:



COMPLETE

