
44inch BASKETBALL SYSTEM
Instruction Manual



Model: BS-HJ44H

Shenzhen Taban Technology Co., Ltd.
Room 1337, Guoxin Investment Building, No. 07,
Gaoxin South 7th Road, Gaoxin District Community,
Yuehai Street, Nanshan District, Shenzhen

Made in China

CONTENTS

Safety Instructions.....01-05

Product Design 06-07

Installation steps.....08-16

Troubleshooting.....17

Customer Support.....18

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

Warning	Not suitable for children under three years old.

【Never Position Near Vehicles】Strictly avoid placing the basketball hoop near your cars. Strong gusts may cause toppling, risking severe damage to vehicles.

【Adverse Weather Precautions】Before the event of severe weather conditions like strong winds or heavy rain, it is highly recommended to lower the basketball hoop to its minimum height and move it indoors to a safe location.

【No Dunking Allowed】This hoop rim is NOT dunk-approved. No hanging/swinging from the rim. Designed for shooting use only.

【Installation Caution】Two-person operation REQUIRED when adjusting height or assembling back board. Prevents accidental tilting that may bend the rim or hoop.

【Base Stabilization is Critical】To ensure safety and maximize the product's lifespan, the base MUST be properly weighted. This is a two-step process:

1. Fill the Base: Completely fill the base compartment with water OR sand.

2. Add Sandbags: For maximum stability, place one or more sandbags (≥ 20kg / 44lbs each) on top of the base platform.

Add more weight to the bottom.You can purchase sandbags yourself, fill them with sand, and then place them on the base.



WARNING: Do not attempt to dunk or hang on the rim.



Warning: Never Position Near Vehicles

Ignoring these safety instructions may lead to serious injury or property damage and will invalidate the warranty.

- An adult must supervise and ensure that all users are aware of and adhere to these safety rules for the product's operation. Pass these instructions on to any future owners of the product.
- To ensure safety, do not attempt to assemble this product without carefully following the instructions.
- Inspect the entire box and all packing materials for parts and/or additional instruction materials. Before starting assembly, read the instructions and identify parts using the hardware identifier and parts list provided in this manual.
- Proper and complete assembly, use, and supervision are crucial for the product's safe operation and to minimize the risk of accidents or injuries. There is a high risk of serious injury if the product is not installed, maintained, and operated correctly.
- Children must always be supervised to prevent them from climbing, mounting, sitting, leaning on, adjusting, moving, or misusing the stand in any way. Failure to heed this warning can result in serious injury or property damage.

- Do not use this product for commercial purposes. It is intended for outdoor, residential use only.
- When using a ladder during assembly, exercise extreme caution. Pay close attention to all instructions and guidance provided with the ladder.
- Inspect the base for leaks prior to each use. Even slow leaks could cause the product to tip over unexpectedly.
- Examine all components for signs of wear or damage before each use.
- Do not operate the product if any parts appear broken or damaged.
- Obtain suitable replacements from Customer Services.
- Do not use any accessories or attachments not included with the set. These may not provide the same level of strength or stability and could lead to accidents or injuries.
- Ensure the pole sections are properly seated and all parts are securely fastened. Failure to do so could result in the pole sections separating during use or while transporting the product. Environmental factors, corrosion, or misuse could lead to product failure.
- If technical assistance is needed, contact customer service.
- The majority of injuries are caused by misuse and/or failure to follow instructions. Exercise caution when using this unit.
- Do not hang on the rim or any part of the product, including the backboard, support braces, or net.
- During play, especially when performing dunk-type activities, keep the player's face away from the back board, rim, and net. Serious injury could occur if teeth or face come into contact with the backboard, rim, or net.
- Do not slide, climb, shake, or play on the base and/or pole.
- After assembling the base, fill the product completely with water or sand. Never leave the product in an upright position without filling the base with weight, as it may tip over causing injuries.
- When adjusting the height or moving the product, keep hands and fingers away from moving parts.
- Do not allow children to move or adjust the product.
- During play, do not wear jewelry (rings, watches, necklaces, etc.). Objects may entangle in the net.
- Mount the product only on a dry, flat, even surface. The surface beneath the base must be smooth and free of gravel or other sharp objects. Punctures can cause leakage and may cause the product to tip over.
- Keep organic material away from the pole base. Grass, litter, etc. could cause corrosion and/or deterioration.
- Inspect the pole product for signs of corrosion (rust, pitting, chipping) and repaint with exterior enamel paint.
- If rust has penetrated through the steel anywhere, replace the pole immediately.
- Do not use the product during windy and/or severe weather conditions; it may tip over. Place the product in the storage position and/or in an area protected from the wind and free from personal property and/or overhead wires.
- When moving the product, use caution to prevent the mechanism from shifting.
- Do not allow water in the tank to freeze. Empty the tank completely before storage.
- While moving the product, do not allow anyone to stand or sit on the base or to add extra weight on the base.
- Do not leave the product unsupervised or play on the product when it is moving.
- Exercise caution when moving the product across uneven surfaces to prevent tipping over.
- Never hang or swing from the product.
- When positioning the product, ensure sufficient space for foreseeable use. Do not mount it under any live electrical wires, utilities, or drains.

Do not use this product for any purpose other than its intended use. Misuse can result in serious injury or property damage.

Two people are required for assembly. Failure to heed this warning could lead to serious injury or property damage.

IMPORTANT

Weather Warning: To prevent damage, move the entire unit indoors for storage in case of severe weather conditions such as blizzards or hurricanes.



Teamwork Required: Assembly and adjustment of this product require at least two adults to ensure safety and prevent injury or damage.

Adults Only Setup: Only adults should perform the assembly. Keep children and pets away from the assembly area until the product is fully installed and secure.



Maximize Stability: For optimal stability, after filling the base with water or sand, also fill the purchased sandbags and place them on top of the base platform.


Product Information

Moedl	BS-HJ44H
Name	44 in Portable Basketball Hoops & Goals
Backboard material	PVC, Transparent backboard
Backboard size	44" x 29.5" x 1.2"
Lifting height	1.05-3.05m(41"-120")
Basket diameter	45cm (18")
Basket material	Iron, plastic
Basket base size	42.5" × 23.6" × 4.9"
Adjustment method	Screw adjustment
Base volume counterweight (maximum volume load capacity)	80 KG/176 lb (It is recommended to use sandbags to increase the bottom weight)






While holding the pole, rotate the basketball system forward until the wheels engage with the ground.
Then, move the basketball system to the desired location.
Carefully rotate the basketball system upright.
Finally, check the system for stability.

Product Design




Product Design

①  Base	②  Backboard
③  baskatball rim	④  Net
⑤  Pedestal	⑥  Top pole
⑦  Middle pole	⑧  Lower pole
⑨  R L Lower Brace	⑩  Lower Brace
⑪  Link rod	⑫  Pin
⑬  Wheel	⑭  Backboard Frame

Ⓐ  M8 * 105 mm x 2	Ⓑ  M8 * 85 mm x 2
Ⓒ  M8 * 90 mm x 1	Ⓓ  M8 * 75 mm x 4
Ⓔ  M6 * 55 mm x 2	Ⓕ  M8 * 50 mm x 2
Ⓖ  M8 * 40mm x 2	Ⓗ  M8 * 20 mm x 1
Ⓘ  M8 * 10 mm x 2	Ⓙ  13 * 14 x 2

Step 1: Install the Lower Brace of the Basketball Hoop Base


1. Use the link rods (11) to connect the two lower braces (10) together. (As shown in the figure).
2. Snap the rotating shaft of the wheel (13) into the back of the base (1)



① Base	⑬ Wheel	Ⓔ M6 * 55 mm x 2
⑩ Lower Brace	⑪ Link rod	E1 E2 E2 E3

Step 2: Install the Basketball Hoop Base


Place the two lower braces (9) on top of the base (1) and the two lower braces (10) underneath the base (1). Then secure them using the screws (F). (As shown in the figure).





⑨ R L Lower Brace	Ⓕ M8 * 50mm x 2	F1 F2 F2 F3

Step 3: Install the Basketball Hoop Lower Pole

1. Use the pin (12) to secure the lower pole (8) in the middle of the lower brace (10).
2. Use the bolt (C) to fasten the lower pole (8) in the middle of the lower brace (9).
3. Use the bolt (H) to fix the pedestal (5) underneath the lower pole (8). (As shown in the figure).




⑤  Pedestal	⑧  Lower pole	⑫ Pin	
Ⓒ  M8 * 90mm x 1	Ⓗ  M8 * 20 mm x 1		


Step 4: Install the Basketball Backboard and Hoop

1. Use screws (A) and (G) to secure the baskatball rim (3) and backboard frame (14) to the backboard (2).

Note: The spring-loaded bolt assembly (A) must be installed in the two holes at the upper end of the baek board (2). (As shown in the figure).


2. Pull open the backboard frame (14), then secure it to the back of the backboard (2) using screws (I).



②  Backboard	③  basketball rim	⑭  Backboard Frame	Ⓐ  M8 * 105 mm x 2
Ⓖ  M8 * 40 mm x 2	Ⓘ  M8 * 10 mm x 2		

Step 5: Install the Basketball Hoop Top Pole

Use screws (B) to secure the upper end of the top pole (6) into the pre-drilled holes of the backboard frame (14).





⑥	Ⓑ	B1 B2 B2 B3
Top pole	M8 * 85mm x 2	

Step 6: Install the Basketball Net and Repair Abnormal Pipes

As shown in the picture on the right,when there is a burr at the pipeconnection or the pipe end is deformed a cardboard or wooden board can beplaced on the bottom of the lower pipe.and the necked part of the pipe can be knocked in.

For the net installation, please follow the sequence from Figure 1 to Figure 4.






Nets installation diagram

④	③
Net	baskatball rim

Step 7: Install the Basketball Hoop Middle pole


Use screws (D) to connect and secure the middle pole (7) and the lower pole (8).



⑦	Ⓓ	D1 D2 D3
Lower Brace	M8 * 75mm x 2	

Step 8: Install the Basketball Hoop


Use screws (D) to connect and secure the Top pole (6) and the Middle pole (7) .The basketball hoop can be tilted for installation. Note the orientation of the backboard.



⑥	Ⓓ	D1 D2 D3
Top pole	M8 * 75mm x 2	

Fill the Base

NOTE:
Secure All Hardware: Before use, ensure all nuts, bolts, and telescopic knobs are fully tightened.
Fill the Base for Stability: The base must be weighted for the unit to be stable and safe.
Recommended Method: For convenience, first fill the base with water, then place the purchased sandbag on top to increase stability.
Alternative: You may fill the base with sand instead. A funnel is recommended for easier filling.
Prevent Leaks: Keep the base away from sharp objects to avoid punctures and leaks.



Troubleshooting

Problem	Cause	Solution
Parts are difficult to assemble.	1. Incorrect installation. 2. Missing parts.	Please follow the steps in the installing video provided.
Knob is difficult to turn.	Incorrect knob installation	Please reinstall this part of the product, as we have already improved the knob.
Difficult to move the product even with the moving wheel.	Incorrect moving method.	To better move the product, please tilt the base more than 40 degrees to the ground.
The backboard feels wobbly. not stable at all.	1. Loose connection of the knob on top. 2. Not enough support from the base.	1. Please tighten the knob on the top of the rebound. 2. Place water or sandbags at the base to weigh it down.
Missing parts.	1. Lost during transportation 2. Lost during installation.	Contact us and we'll reship the parts to you.
Wobbly base.	Not enough water/sand added to the bottom.	Add more weight to the bottom. You can purchase sandbags yourself, fill them with sand, and then place them on the base.

Tighten Screws: It is recommended to check and tighten all bolts and knobs every three months to maintain stability and safety.
General Inspection:Regularly check for signs of rust, wear, or damage, especially if the unit is kept outdoors.

Product Highlights

1. Easy Height Adjustment:Enjoy the freedom to easily set the rim to your desired height.

2.Easy to Move:Integrated front wheels allow for convenient relocation.

3.Durable Construction:Built to last with a 44-inch polycarbonate backboard, a bumper rim, an all-weather net, and heavy-duty steel poles.

4.Safe & User-Friendly:Designed for safe and convenient play for the whole family.

Customer Support

If you need help regarding product issues, after-sales service, or other relevant problems, please contact us via the order number.

Please have the following information ready when requesting service:

Problem Description

Note: Products purchased directly from us benefit from our after-sales service. If the purchases are made from other selling teams, we recommend you contact them for warranty issues.