



# ASSEMBLY INSTRUCTIONS

---



## TOOLS REQUIRED



Screwdriver  
( Not included)



(Included)  
Allen Wrench



2 - People

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



## **CHECK BEFORE STARTING**

☐

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed are all accounted for.

☐

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!


☐

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.


# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.





## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly  
and insert screws or bolts into  
their respective holes.




Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Save the instructions and store  
any supplied tools for later  
maintenance.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.



After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.


**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**

# ROUND DINING TABLE




## PARTS

1




TOP  
2 pcs.

2




LONG CONNECTOR  
1 pc.

3




SHORT CONNECTOR  
2 pcs.

4



LEG1  
1 pc.


5



LEG2  
1 pc.


## HARDWARE

A




METAL BRACKET  
4" x 4" x 1/8"  
1 pc.

B



WOOD DOWEL  
Ø10 x 30MM  
4 pcs.

C



BOLT  
1/4" x 1-1/4"  
24 pcs.

D



BOLT  
1/4" x 1-1/4"  
4 pcs.

E



SPRING WASHER  
Ø1/4"  
24 pcs.

F



FLAT WASHER  
Ø1/4"  
24 pcs.

G



ALLEN WRENCH  
M4  
1 pc.

# ASSEMBLY INSTRUCTIONS


1

DO NOT FULLY TIGHTEN ALL BOLTS UNTIL ASSEMBLY IS COMPLETED.

Part 1 x 2pcs

Hardware B x 4pcs

Align Wood Dowels (B) into the designated holes on the two table tops (1).



2

Part 4 x 1pc


Part 5 x 1pc

Hardware A x 1pc

Hardware D x 4pcs

Hardware G x 1pc


Attach the Leg2 (5) into the Leg1 (4), then secure by metal bracket(A) and bolts(D).



# ASSEMBLY INSTRUCTIONS

## 3


Part 2 x1pc  
Part 3 x2pcs  
Hardware C x 8pcs  
Hardware E x 8pcs  
Hardware F x 8pcs



Align Long Connector (2) and Short Connector (3) to the Legs then secure by using bolt (C) with spring washer (E) and flat washer (F).

## 4


Hardware C x 16pcs  
Hardware E x 16pcs  
Hardware F x 16pcs



Align Connectors to the Top then secure by using bolt (C) with spring washer (E) and flat washer (F).

# ASSEMBLY INSTRUCTIONS

5



## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.