

**PLEASE DO NOT RETURN TO STORE**




Please do not return this product to the retailer!  
We are able to assist you in ANY way!

If you find that you have any trouble with assembly or  
missing or damaged parts please contact the seller.

# User Manual ASSEMBLY INSTRUCTION

JDT-2216

Right corner from inside  
70.8 L\*23.6 W\*39.4 H Inch



# Parts List


| NO. | Drawing | Dimension     | QTY |
|-----|---------|---------------|-----|
| 1   |         | 1000*200*15mm | *1  |
| 2   |         | 400*200*15mm  | *1  |
| 3   |         | 998*235*15mm  | *1  |
| 4   |         | 583*235*15mm  | *1  |
| 5   |         | 235*178*15mm  | *2  |
| 6   |         | 1800*600*25mm | *1  |
| 7   |         | 1798*725*15mm | *1  |
| 8   |         | 725*560*15mm  | *1  |
| 9   |         | 725*544*15mm  | *1  |
| 10  |         | 725*560*15mm  | *1  |
| 11  |         | 350*385*15mm  | *1  |

| NO. | Drawing | Dimension    | QTY |
|-----|---------|--------------|-----|
| 12  |         | 350*142*15mm | *1  |
| 13  |         | 400*142*15mm | *1  |
| 14  |         | 490*350*15mm | *1  |
| 15  |         | 400*80*15mm  | *1  |
| 16  |         | 400*80*15mm  | *1  |
| 17  |         | 515*80*15mm  | *1  |
| 18  |         | 380*140*15mm | *1  |
| 19  |         | 350*86*15mm  | *1  |
| 20  |         | 350*86*15mm  | *1  |
| 21  |         | 295*86*15mm  | *1  |
| 22  |         | 305*344*4mm  | *1  |

Scan the QR code to watch the product  
installation video




# Hardware Fitting





| NO. | Drawing                                                                                         | QTY |
|-----|-------------------------------------------------------------------------------------------------|-----|
| A   |              | *65 |
| B   |              | *65 |
| C   | <br>8*60mm   | *2  |
| D   |              | *2  |
| E   | <br>3.5*35mm | *4  |

| NO. | Drawing                                                                                         | QTY |
|-----|-------------------------------------------------------------------------------------------------|-----|
| F   | <br>3.5*14mm | *16 |
| G   |              | *1  |
| H   | <br>4*18mm   | *2  |
| I   | <br>4mm      | *1  |
| J   |              | *1  |




|    |                                                                                   |   |     |                                                                                   |   |
|----|-----------------------------------------------------------------------------------|---|-----|-----------------------------------------------------------------------------------|---|
|    |                                                                                   |   | I*  |  | G |
| I* |  | J | 10* |  | F |
| 2* |  | H | 2*  |  | D |






|   |                                                                                   |    |
|---|-----------------------------------------------------------------------------------|----|
| A |  | *4 |
| B |  | *4 |


## Cam Coupling Using Methods




**Step1.**  
Connect the cam coupling A as directed in the assembly instructions using hand.



**Step2.**  
Screw the cam coupling A as directed in the assembly instructions.



**Step3.**  
Push the cam coupling A into the entry hole.




**Step4.**  
Insert the cam coupling B as shown in the instructions.



**Step5.**  
Turn the cam coupling B clockwise with a screwdriver



**Step6.**  
Put on Beautycam.



**Step7.**  
Finished.

You should feel a click when the camlock is locked in place.  
The joint is now secure.

