



USER'S MANUAL

Christmas Tree

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

HARDWARE



SCREW
3PCS



CAP

NOTE: Please remove the circular protector caps on the end of each pole before assembling.

If the caps are broken, it will not affect the use.








1 PERSON
ASSEMBLY







APPROXIMATELY
15 MIN.
ASSEMBLY

8FT TREE PARTS






5-7FT TREE PARTS






4FT TREE PARTS



PRODUCT ASSEMBLY



CAUTION

- Firmly secure all screws before use.
- Product is intended for indoor use only.
- Do not place this tree in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way that is inconsistent with the manufacturer's instructions.

CLEANING&STORAGE

- Store this tree in a cool and dry place away from heat and moisture.
- Before putting this tree in storage, do the following.
 - Completely remove all decorations.
 - Clean the tree with a slightly dampened cloth and let it dry naturally.
 - Raise all branches to original upright position, make sure not to damage any branches in the process.