



13

TURN 180°



Recommended Maximum Weight



*Unit in Pound(lbs)

WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.


Assembly Instruction

00:30


Approx. 30 minutes













Recomm. 2 Persons




Tools Required





HARDWARE & PARTS LIST

NO	HARDWARE LIST	QTY
1	LONG POLE 	4pcs
2	SMALL LEG 	2pcs
3	CAM-LOCK PILLAR 	4pcs
4	CAM-LOCK NUT 	4pcs
5	LONG SCREW 	24pcs
6	SHORT SCREW 	4pcs
7	DOWEL 	14pcs
8	POWER PIN 	16pcs
9	NAIL LEG 	6pcs
10	STICKER 	24pcs


NO	PARTS LIST	QTY
A	LARGE TOP PANEL	1pc
B	SMALL TOP PANEL	1pc
C	BACK LEFT SIDE PANEL	1pc
D	BACK RIGHT SIDE PANEL	1pc
E	FRONT SIDE PANEL	2pcs
F	RIGHT SIDE PANEL	1pc
G	CENTER BACK PANEL	1pc
H	SHELF PANEL	2pcs
I	SUPPORT PANEL	1pc
J	BACK PANEL	1pc




- USEFUL HINTS BEFORE YOU START:**
- 1. Read each step carefully before starting.
 - 2. It is important that each step is performed in correct order to avoid difficulties.
 - 3. Identify, sort and count the parts before assembly.
 - 4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
 - 5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
 - 6. Using incompatible hardware might cause damage to product.



9




10



ASSEMBLY INSTRUCTIONS

BEFORE YOU BEGIN, PLEASE READ ASSEMBLY INSTRUCTION CAREFULLY, FOLLOW THEM STEP BY STEP.

1



2

