You can contact us at Amazon.

From your Amazon order details page, select "Order", "Sold by", "Contact selle".

Warranty Card

The warranty periods and warranty services referred to above are intended as a guide only and variations may occur. If there are differences between the warranty card and information included with the product and the information shown above, the warranty

card and information included with the product shall apply. The warranty periods apply from the first date of purchase of the product. To obtain warranty service, the original proof of purchase will be required and any serial number

affixed to the product must be complete and undamaged. The warranty covers defects in materials and workmanship. The warranty may not apply to consumable items included with or in the product, which may have a reduced or no warranty period.

The warranty card and warranty information included with the product will state specific exclusions to the warranty (e.g. where a defect is caused by misuse or unauthorised repair of the product) which must be checked before requesting service under the warranty.

CARE & MAINTENANCE

- 1.Do not put hot items on or near the furniture. Keep away from sources of ignition.
- 2. Children should not climb or jump on the furniture.
- 3.Do not clean the furniture with harsh cleansers or polish. Stains may be removed by using mild soap solution and damp cloth.
- 4. To obtain the longest life span of your outdoor products, minimizing the extended exposure to direct rain, snow, sunshine is recommended. Whenever possible, cover the products and/ or place under patio umbrellas or awnings
- 5. Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product


Thank for your purchase!

8



Ergonomic Office Chair

PARTS



2


RETURN POLICY

- All returns must be approved by customer service departmentbefore they can be mailed back within 30 days ofreceipt.
- Unauthorized returns, all other returns are non-refundable.
- If the item arrives without damaged or defective, the buyer will berequired to be responsible for all returned shipping costs.
- When we receive all items, please repackage them in the original boxes.
- We are not responsible for any package returned to us that was not our original shipment.

Our Commitment:

From the beginning of your purchase, within three years we replace your damaged office chair accessories for free.

MULTIFUNCTIONAL



TIPS


the armrest and clamp it on the seat cushion for installation. 2. If the chair cannot be raised or lowered after the assembly, you could

1. Put the seat cushion on top of the carton of the swivel chair, and then slightly open

sit on it for a few minutes to add force to it. 3. The small iron wire on the wheel does not need to be taken off, it is inserted directly.If

the strength is not enough, you can use a hammer to knock it in.

ASSEMBLY STEPA



3

