







IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.

(1)X1	(2)X1	(3)X1 (L)x1 (R)
		
BACK	SEAT	ARM
(4)X1	(5)X1	(6)X5
		
GAS LIFT	BASE	CASTERS
(7)X1	(A)X4  M8*22 MECHANISM SCREW (B)X4  M8*36 ARM SCREW (C)X4  M6*30 L-BAR SCREW (D)X4  ARM CAPS (E)X1  ALLEN KEY	
	MECHANISM	



Note: Please tighten all arm screws using allen key before step 6

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

