



ASSEMBLY INSTRUCTIONS

HYSB-002-HT




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



















Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes






ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(I)		X1
(B)		X1	(J)		X1
(C)		X1	(K)		X3
(D)		X1	(L)		X3
(E)		X1	(M)		X3
(F)		X1	(N)		X3
(G)		X2	(O)		X3
(H)		X2	(P)		X1

ASSEMBLY INSTRUCTIONS

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	 Ø8*30mm	X20+2	6	 Ø3*15mm	X25+2
2		X20+2	7	 Ø4*30mm	X24+2
3		X20+2	8		X8
4		X4	9		X2
5	 Ø3*14mm	X24+2	10		X1

ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

1





(A) 1PC



(B) 1PC




(2) 12PCS




ASSEMBLY INSTRUCTIONS

2




Ⓒ 1PC



Ⓓ 1PC




② 4PCS




ASSEMBLY INSTRUCTIONS

3





Ⓔ 1PC



Ⓕ 1PC




Ⓐ 4PCS




ASSEMBLY INSTRUCTIONS


4




③ 2PC



③ 8PCS




① 8PCS




ASSEMBLY INSTRUCTIONS


5



③ 4PCS




① 4PCS




ASSEMBLY INSTRUCTIONS


6




A 1PC



3 8PCS




1 8PCS



ASSEMBLY INSTRUCTIONS


7




(P) 1PC



(8) 8PCS




Ø3*15mm
(6) 25PCS




ASSEMBLY INSTRUCTIONS


8




(H) 1PC



(J) 1PC



(I) 1PC




(4) 4PCS



Ø3*14mm

(5) 8PCS



ASSEMBLY INSTRUCTIONS

9




Ø3*14mm

⑤ 16PCS




⑨ 2PCS



ASSEMBLY INSTRUCTIONS

10




①

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm




②

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm



③

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


11

Common Door Panel Issues:




ASSEMBLY INSTRUCTIONS


12




(K) 3PC




(L) 3PC



(M) 3PC



(N) 3PC




(O) 3PC




Ø4*30mm

(7) 24PCS




ASSEMBLY INSTRUCTIONS

13




ASSEMBLY INSTRUCTIONS

14



10 1set

A




1pcs

B




2pcs

C




Ø8*3/4"
1pcs

D




Ø8*1-1/2"
1pcs

E



1pcs



WALL

