



ASSEMBLY INSTRUCTION



Floating Swivel Mount



Universal Wall Mount

TV sold separately














Table-top Display


PARTS LIST

Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.

								
(A) Top Shelf Frame		1pc	(B) Middle Shelf Frame		1pc			
								
(C) Bottom Shelf Frame		1pc	(D) Mounting Frame		1pc			
								
(E) Right Leg		1pc	(F) Left Leg		1pc	(G) Monitor Bracket		2pcs
								
(H) Spine Top		1pc	(I) Spine Bottom		1pc	(J) Swiveling Bracket		1pc


HARDWARE LIST

Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.




(1) Power Socket

1pc




(2) Cable Wheel

2pcs




(3) Parts Lock

2pcs




(4) Bolts 1/4"x15mm

32pcs



(5) Bolts 1/4"x30mm

6pcs




(6) Flat Washer 1/4"

6pcs




(7) Screw F4x12mm

2pcs



(8) adjustable foot button


4pcs




(9) Allen Wrench(4mm)&Phillips Head Screwdriver

1pc


Step:1




Step:2




Step:3




Step:4




Step:5



Step:6




Step:7




Step:7-1

Step:8



Assembly is completed.



Please note : You can adjust the leg levels on the end of the legs to level if the stool not level.
The stool is now ready to use.