


ASSEMBLY INSTRUCTION



+ Do Not Use Power Tools




+ Suggested Adults




+ Parts Included


① LOVESEAT BASE
1PC



② CHROME FRONT LEG
2PCS



③ GOLD FRONT LEG
2PCS



④ CHROME BACK LEG
2PCS



⑤ GOLD BACK LEG
2PCS



⑥ FOOT PAD
8PCS



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # - Loveseat Base
- Part # - Chrome Front Leg
- Part # - Gold Front Leg
- Part # - Chrome Back Leg
- Part # - Gold Back Leg
- Part # - Foot Pad

Do not assemble if any of the following

Hardware parts missing:

- Part # - Allen Wrench
- Part # - Bolt

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Hardware Included

A ALLEN WRENCH
Ø5/16 *66MM 1PC





B BOLT
M6*70MM 8PCS





ASSEMBLY INSTRUCTION

1



2



3

