
## 10x8 ft / 9x9 ft Outdoor Cantilever Umbrella with Solar Powered LED Lights



Tips: Weight base is not included in this item. Please buy it separately.

#### **General Guidelines:**

- Please read the following instructions carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps.
- Please contact us when further information and help are needed.

#### Notes:


- Personal injury and/or damage to the product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- Carefully check accessories when opening the package. If anything is missing or damaged, please contact us immediately.
- Do not use the umbrella without an umbrella stand (NOT included).
- This umbrella is only used for shading and decoration purposes.
- Store the umbrella in a dry, sheltered place, such as a garage or basement during high winds, rainy days, and the off-season.
- Never force your umbrella open. The umbrella mechanics should open gently and easily.
- Do not use sharp tools or equipment such as a knife or scissors when removing the protective material, as it may damage the product.
- · After receiving the product, connect the LED light plug to the solar panel before using it.
- Put the solar umbrella in direct sunlight to charge the batteries for 8 hours before the first use.


### Warnings:

- Keep children away when assembling the product. Small parts are included in the package; they may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep the umbrella away from fire; do not use it during extreme cold and heat, and severe weather conditions like rainy, windy, snowy days, and hailstorms, etc.
- When using the tilting mechanism to change the direction, fully press the push-button and do not forcibly adjust it by hand to prevent unnecessary damage.
- When the battery needs to be replaced, please use a battery of the same specifications and capacity.
- Do not throw the battery into fire or heat.
- The battery should be recycled or treated according to state or local requirements.

### **Daily Maintenance:**


- Clean the canopy with a soft cloth moistened with a neutral detergent.
- Store it after completely drying, which will help reduce the growth of mold.
- Do not machine wash, do not dry.
- Do not iron.








# CAUTION


Please pull and loosen the umbrella ribs by hand, so they're not entangled, before attempting to open the umbrella by crank.






































Tips: Weight base is not included in this item. Please buy it separately.

