

# DINING CHAIR

---

## ASSEMBLY INSTRUCTION



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY INSTRUCTION

#### ASSEMBLY TIPS:





- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

#### ▲WARNING!





- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intend for commercial establishment.

ASSEMBLY TIME PER UNIT	5 MINUTES
------------------------	-----------

#### PARTS IDENTIFICATION

A	Back and Seat		1PC
B	Front Leg		2PCS
C	Back Right Leg		1PC
D	Back Left Leg		1PC

### HARDWARE PACKAGE

1	SHORT BOLT		M8*60	8pcs
2	ALLEN KEY		M8	1pc
3	LOCK WASHER			8pcs
4	FLAT WASHER			8pcs

## ASSEMBLY INSTRUCTIONS

