


CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List



Product Dimensions: 43.3"W×25.98"D×16.54"H



HW1x1	HW2x16	HW3x12	HW4x12	HW5x12	HW6x8
	6x16mm	6x45mm	Ø15	Ø7.8x30mm	5x45mm
HW7x8	HW8x16	HW9x8	HW10x8		
4x35mm	3.5x14mm	6x27mm	Ø10		



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 45 minutes.


1




2




3




4





5




6




7





8




9




10




11



12



13



14

