

Drawer Storage Tower

Instruction Manual

CAB-5HBC-48IN



EST 9:00AM--17:00PM




HJ-Customer-Service@outlook.com




(909)637-7665 | (909)637-7593

1 Component List




2 Package List

Ax1




Right Frame

Bx1




Middle Frame

Cx1




Bottom frame

Dx1




Bottom frame

Ex1




Top Cross

Fx1




Bottom Cross

Gx1



Top Panel

Hx4




Left Slats

Ix1



Top Broad


Jx5



Drawer


Kx5

1x4




Adjusting Foot

2x12




Screws
M6 x 22mm

3x16




Screws
M6 x 10mm

4x8




5x1




Wrench

6x10




Screws
M4 x 10mm

7x2




Screws &
Expansion Tubes
M4x60mm

8x5





Drawer Handle


Step 1





Tighten the screws by 50%




Step 2





Tighten the screws by 50%




Step 3





Tighten the screws by 50%



Step 4




Tighten the screws by 100%




Turn it over.

NOTE: Make sure all Bolts are 100% tightened before use.



Step 5



Step 6



Step 7



NOTE: Electrodrill and hammer is not included.



Technical Support

(909)637-7665 | (909)637-7593

Other Info

HJ-Customer-Service@outlook.com

Thank you for choosing this product. We strive to provide you with the best quality products and service in the industry. Should you have any issues, please don't hesitate to contact us.