

PF052



PF052



PF052

Directory

Product introduction

Main structure description 01
List of parts 02
Operating panel 02

Installation instructions

Complete installation 03
Add cat litter 04
Power on 04

Daily Maintenance

Clean the collection bin..... 05
Rotating drum cleaning..... 06
Aromatherapy box replacement...07


Safety warning


Indicates prohibited content 08
Indicates mandatory content 09
Indicates attention content 09

Service guide

Product parameter 10
Fault self-test..... 11
Skill 12
Warranty instructions 13

Main structure description





Installation diagram

(The picture is for reference only Products in kind shall prevail)

List of parts

PF052



Instruction x1



Power Adapter x1



Garbage bag x1

Operating panel

Cleaning button

- **Usage:** Press once to start cleaning, long press for 3s to empty the cat litter
- **Steady green light:** In operation
- **Slow-flashing yellow light:** Waste collection bin full

Manual mode button

- **Usage:** Long press for 3s to enter manual mode,then long press for 3s to exit
- **Steady green light:** Manual mode activated

Power button

- **Usage:** Long press for 3s to power off; press once to power on
- **Steady green light:** Power on

Child lock

- **Usage:** Hold the manual button, then hold the cleaning button—keep both pressed for 3 seconds to lock/unlock.
- **Steady white light:** Child lock enabled


Digital Display Window

- **Number 1:** Delayed waste removal
- **Number 2:** Anti-pinch activated
- **Number 3:** Waste collection bin full
- **Number 4:** Induction radar activated
- **Number 5:** Motor protection

Installation instructions

PF052

Complete installation




①. Remove other components from the drum and place the machine (as shown in the picture) on a hard and flat surface.




②. Take out the four support feet in sequence to find the dot position, align with the "Unlock Mark" and insert it. Rotate the "Lock mark" counterclockwise to complete the installation.



③. Align the roller shaft with the groove and install it on the base. Use both hands to clamp one side of the side protective casing inward, and repeat the same operation on the other side.



④. Put the garbage bag over the two rear corners, then pull it forward and secure it against the two front corners, and make it even.



⑤. Align the waste collection bin with the installation slot at the bottom of the machine and push it into place.




⑥. After installing the drum, side protective casings and the collection bin, place the machine on a hard and flat ground.


Attention!

Before installation, please carefully read the instruction manual and check the accompanying accessories.
For cats under 3.3 lb, please use manual mode.


Add cat litter



①. Long press ⏻ for 3 seconds to shut down.




②. Pour an appropriate amount of cat litter. (Recommendation: Use "fine-grained" cat litter)




③. The amount of cat litter poured should be between the "MIN" and "MAX" markings.

Attention! Before adding cat litter each time, please press the cleaning button briefly once to reset and level the litter after each addition.
Recommendation: Use "fine-grained" cat litter! It is recommended that the cat litter has a length of no more than 10mm and a diameter of no more than 1.5mm.

Power on




①. Insert the power adapter connector into the port on the rear of the product, ensuring it is fully inserted.




②. Insert the plug blade end of the power adapter into the electrical outlet.

Daily maintenance


Clean the collection bin



①. Pull out the collection bin.




②. Take out the garbage bag and tighten the handle to seal it.




③. The collection bin can be washed dry with clean water, and then reset after loading a new garbage bag.


Rotating drum cleaning




①. Cut off the power supply and pull the power adapter out of the back hole of the product.




②. Grasp the handle holes on both side protective casings and pull them out horizontally.



③. Lift out the rotating drum.




④. Wipe the interior of the product with a damp towel.




⑤. Locate the sieve mesh inside the rotating drum, grasp its end, pull upward to disengage from the clips, and remove.



⑥. Take out the sieve mesh.




⑦. The rotary drum is cleaned directly with water.




⑧. The sieve mesh should be cleaned separately, dried and then reset.

PF052

The installation and disassembly of the sieve mesh



①. Step 1: Hook the snap into place and then press it down to secure it.
②. Step 2: Insert the left sleeve into the pin.
③. Step 3: Insert the right sleeve into the pin.



①. Step 1: Pull backward to release the right snap.
②. Step 2: Pull backward to release the left snap.
③. Step 3: Grasp and rotate upwards to remove the sieve mesh.

Note! Maintenance work is not within the scope of maintenance.

· Matching special garbage bags should be used to ensure the cleaning effect of products.
· Contact us if you have any questions during the installation and disassembly of the sieve mesh.
Email: hofficeservice@gmail.com

Safety warning

PF052

Note! To ensure safety and avoid injury and property damage to yourself and others, please observe the following safety precautions. Misuse may result in accidents.

⃠ Indicates prohibited content



Keep out the sun | No flammable articles | No wet area | Do not touch with wet hands | Avoid washing or submerging the unit in water | Do not place on uneven ground

· The machine should be placed in a cool and dry place in the room. Avoid the place exposed to strong sunlight, otherwise it will easily cause aging of product parts.
· Do not allow young children to handle, touch, approach or climb. Children and people with intellectual disabilities should use it with a guardian.
· Do not use gasoline and other organic solution to wipe the fuselage, the product is strictly prohibited to wash, water. Do not put the product in contact with or near inflammable and explosive materials.
· In order to save electricity, disconnect the corresponding power switch when not in use for a long time, and clean the remaining sand in the machine. Install and fix the machine before it can be used.
· Do not connect the booster transformer to the power plug.
· The machine is not allowed to be used in the place where there is water spraying, and electrical appliances are not allowed to be used in the cabinet.

Indicates mandatory content



Need professionals

- It is strictly prohibited to extend the power cord arbitrarily to avoid fire
- If the power cord is damaged, it must be replaced by the manufacturer, maintenance department or profes sionals to avoid danger

May cause minor injury or damage to property

- When cutting off the power supply, do not pull the power cord directly to prevent it from being broken. Keep flammable and volatile substances away from the machine. In the transportation and loading and unloading process, should be handled lightly, prevent a collision scratch products and accessories.
- The machine shall not be installed outdoors. Should be placed in a ventilated, dry, temperature of 4-40℃, relative humidity does not exceed 60%, In an environment without corrosive gases. After the machine is out of service, empty the cat litter in the bucket and the cat feces in the collection bin.
- Keep the power plug clean. Do not insert or remove the power plug with wet hands.
- There will be slight vibration and noise when the drum is rotating, which is a normal phenomenon.
- Wet or dusty areas may cause circuit damage. High magnetic appliances are nearby, which may cause fire, product damage or circuit failure.
- When moving the product, handle it gently and avoid dragging it.
- Do not place other items on the top of the product, which may affect the normal work of the product.
- The product can only be used on the special accessories provided by our company.

Service guide

PF052

Product parameter

Due to product improvement, the following parameters are subject to change, mainly the product nameplate.

Model number	
Rated voltage	12V ⎓
Rated power	9W
Product size	531*445*583mm
Litter Container Capacity	8L

Fault self-test

PF052

Note! The following is the common judgment and inspection, if simple treatment cannot be eliminated, please send to the maintenance network or Call the customer service hotline for consultation. Please do not disassemble and repair by yourself to avoid danger or Cause damage to the product.

Problem	Cause	Treatment method
The digital display shows the number 1, and the drum does not rotate	Delayed waste removal. (protection mechanism)	Please confirm that the cat has left the litter box, and then wait for the product to clean automatically.
The digital display shows the number 2, and the drum does not rotate	The infrared sensor inside the drum is blocked.	Check if there is any foreign matter blocking the infrared sensors on both sides of the rotating drum. Clean it off to restore normal operation.
The digital display shows the number 3, and the drum does not rotate	The infrared sensor of the waste collection bin is blocked.	Check if the waste collection bin is full,or if there is any foreign matter blocking the infrared sensor beads on both sides. Clean them up to restore normal operation.
The digital display shows the number 4, and the drum does not rotate	Microwave radar trigger.	Unplug the power supply, remove the drum to inspect the inner wall of the main unit and clean it thoroughly
The digital display shows the number 5, and the drum does not rotate	Product accessories are not installed in place; The required adapter is not used.	Check and reinstall product accessories;Check that the adapter power matches that of the machine nameplate.

Skills:

PF052

1. The machine is placed on a flat hard ground, and there are four black parts on the bottom that should be in contact with the same plane.

2.Make sure the cat weighs more than 1.5kg, otherwise it may cause the cat to be injured.

Maintenance service guarantee
In case of product failure, please contact our local distribution service network or customer service center. The litter box is guaranteed for one year. Consumables are not covered by warranty, please purchase them by yourself after use.

The start date of the warranty period is subject to the invoice of the product. The following conditions are not covered by the warranty:
1. Damage caused by improper use, storage and maintenance of consumers.
2. Damage caused by disassembly and repair without the company's designated maintenance department.
3. The model of the invoice is inconsistent with the model of the maintenance product or altered.
4. No valid invoice.
5. Force majeure causes damage.
6. We are not responsible for the quality accidents caused by the non-standard gifts or accessories of our company.
7. This product is used for non-household purposes, the whole machine warranty will be implemented for half a year.
8. Failure caused by human or improper use is not covered by warranty.
9. Please use the spare parts provided by our company. Old parts cannot be reused.
10. Failure or damage caused by forced use of the product beyond normal conditions is not covered by the warranty. For products not covered by warranty, our customer service center is still willing to serve you.

Product implementation standards:
GB 4706.1-2005

Note! All contents in this manual have been checked. If there is any typographical error or misunderstanding in the content, please refer to the company. If there is any technical improvement, it will be included in the new manual without prior notice. If the appearance and color of the product are changed, the physical object shall prevail.

PF052

PF052

PF052