SLEIGH STYLE BABY CHANGING TABLE WITH HAMPER AND 3 BASKETS

Assembly Instructions. Adult Assembly Required.
Read all instructions before use.

This manual is part of the product and must be kept for future reference.



MODEL NUMBERS*:

White Cherry Black Natural Honey Espresso

Gray

* These numbers are needed if replacement parts are requested



If you need product parts, see below or Page 2!

BEFORE YOU BEGIN ASSEMBLY:

Check all parts and hardware.




USE AND CARE INSTRUCTIONS:


Wipe the table, pad, and safety belt clean with a damp cloth and mild soap as needed. Spot clean baskets as needed. Do not immerse baskets in water. Hamper bag can be removed for machine washing (cold water, tumble dry low or no heat or air dry).





WARNING - FAILURE TO FOLLOW THESE WARNINGS AND THE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH


READ ALL INSTRUCTIONS before use of this changing table. Keep instructions for future use. Product and/or hardware may include small parts or screws with sharp points. **Choking Hazard!** Keep unassembled parts out of the reach of small children. Use only the changing pad, parts, and hardware provided by Badger Basket. Do not use the changing table if it is damaged, broken, or missing any parts. **FALL HAZARD** - To prevent death or serious injury, always keep baby within arm's reach. NEVER leave your baby unattended, not even for a moment, when you are changing Baby's diaper. ALWAYS use the safety belt provided; and as an extra precaution keep at least one hand on your baby at all times. **DO NOT** allow any children to climb or play on the table. **Periodically check** to make sure all the bolts and screws remain tight. This table is suitable for use with children weighing up to 30 lbs. (13.64 kg). Buckle child securely using the safety belt whenever child is on the table. Keep child's skin/body clear of the safety belt buckle when snapping/unsnapping to prevent injury. Buckle is not securly fastened unless you hear an audible "click" to indicate the parts have connected securely together. **NEVER** allow child to stand up on the table due to risk of falls and injury or death. **NEVER** use the changing table without the safety belt and metal bar properly installed. **ALWAYS** secure the changing pad to the changing surface by placing it onto the top shelf and ensuring it's underneath, not on top of, the safety belt.
















ATTACH THE TOP/MIDDLE BASKET TRACKS (PARTS K AND L) TO THE RIGHT SIDE PANEL (PART B) AND VERTICAL POSTS (PART F) USING PART S BOLTS. ATTACH THE BOTTOM BASKET TRACKS (PARTS M AND N) TO THE BOTTOM RAILS (PARTS E) USING PART T SCREWS.


THERE ARE DRAWER STOPPERS ON ALL OF THE K, L, M, AND N BASKET TRACKS WHICH MUST ALL BE POSITIONED AT THE BACK OF THE CHANGING TABLE.


Ø4x19mm Ø6x28mm

Tx4 Sx8









BUCKLE CHILD SECURELY USING THE SAFETY BELT (PART W) WHENEVER CHILD IS ON THE TABLE. UNCLIP AND SEPARATE THE BUCKLE BY SQUEEZING THE TABS ON THE SIDES TO RELEASE THE BUCKLE TONGUE FROM THE BUCKLE. PLACE CHILD ONTO CHANGING SURFACE AND SNAP THE BUCKLE AND BUCKLE TONGUE BACK TOGETHER. KEEP CHILD'S SKIN/BODY CLEAR OF THE BUCKLE WHEN SNAPPING AND UNSNAPPING TO PREVENT INJURY. BUCKLE IS NOT SECURELY FASTENED UNLESS YOU HEAR AN AUDIBLE "CLICK" TO INDICATE THE PARTS HAVE CONNECTED SECURELY TOGETHER.

NEVER ALLOW CHILD TO STAND UP ON THE TABLE DUE TO RISK OF FALLS AND INJURY OR DEATH. NEVER USE THE TABLE WITHOUT THE SAFETY BELT (PART W) AND METAL BAR (PART V) IN PLACE.

ALWAYS SECURE THE CHANGING PAD TO THE CHANGING SURFACE BY PLACING IT ONTO THE TOP SHELF AND ENSURING THAT IT'S UNDERNEATH, NOT ON TOP OF, THE SAFETY BELT.