


Assembly Instructions & Care Guide



Illustrations in this guide are for reference only and may differ slightly from the actual product.

CONTENT

Before You Start

Overview	01
Caution	01
Material Specifications	01

Installation Guide

Exploded Views	02
Component Parts	03
Hardware	04
Assembly Directions	05–31
Troubleshoot	32

Usage and Maintenance

Use and Care	33
--------------------	----

Other

Help Center	34
-------------------	----

Before You Start

Overview

1. Check and ensure you have received all packages and necessary parts.
2. Prepare adequate assembly space. We recommend using pads or cardboard to prevent the floor from scratches.
3. Read the instructions to familiarize yourself with the assembly requirements. Allow sufficient time and have someone available to assist you if needed.
4. Place all hardware on a soft surface for easy identification.
5. The seller is not responsible for any damage or injury caused by improper assembly or use.
6. If you need further assistance, please contact us

Caution

1. Children must not assemble this product. During assembly, keep small parts away from children as swallowing or inhaling them could be fatal.
2. Do not allow children to stand, climb, or play on the product, as it may tip over and cause serious injury.
3. Keep plastic packaging bags away from children to prevent risks of suffocation.
4. Avoid sharp objects and corrosive chemicals to prevent product damage or personal injury.



Material Specifications

Solid Wood


Natural grains, scars, and color variations are inherent in real wood, which contribute to its unique beauty. Slight color changes may occur under different lighting and angles, due to variations in wood grain and light intensity.

Installation Guide


Exploded Views




1. Install the screw rod




2. Tighten the screw rod clockwise




3. Pay attention to tightening the screw rod



4. Installation plate




















5. Align the arrow of the eccentric component with the screw rod








6. Pay attention to aligning the arrow of the eccentric part with the screw rod

Component Parts

	①x1		1615 x 632mm		②x1		996 x 630mm		③x1		996 x 630mm
	④x1		1540 x 332mm		⑤x1		1540x 332mm		⑥x1		1540 x 332mm
	⑦x1		1540 x 291mm		⑧x1		1540 x 291mm		⑨x1		588 x 250mm
	⑩x1		588 x 250mm		⑪x1		550 x 198mm		⑫x1		550 x 198mm
	⑬x1		1199 x 198mm		⑭x1		520 x 198mm		⑮x1		520 x 198mm
	⑯x1		1144 x 198mm		⑰x1		490 x 198mm		⑱x1		490 x 198mm
	⑲x1		1089 x 198mm		⑳x1		470 x 178mm		㉑x2		1089 x 235mm
	㉒x1		1536 x 260mm		㉓x1		1536 x 355mm		㉔x1		1536 x 355mm
	㉕x1		720 x 768mm		㉖x1		720 x 768mm				


Hardware

☐	Ax80 (+8)  Ø6 x 39mm	☐	Bx80 (+8)  Ø15 x 10mm	☐	Cx2  155 x 24mm	☐	Dx8  100 x 70mm
☐	Ex5  Ø80 x 2mm	☐	Fx8  Ø3.5 x 25mm	☐	Gx2  75 x23x20mm	☐	Hx12  H52mm
☐	Ix1  162X55X40mm	☐	Jx6  490mm	☐	Kx4  M7 x 38mm	☐	Lx116 (+10)  Ø3.5 x 14mm
☐	Mx4  Ø4 x 30mm	☐	Nx19 (+1)  M10 x 40mm	☐	Ox6  	☐	Px54 (+5)  Ø4 x 14mm
☐	Qx4  Ø3.5 x 18mm	☐	Rx4  Ø4 x 16mm				

Install your new product with care, following the instructions step-by-step. Do not skip any steps. Carefully distinguish between left and right components. Do not over-tighten screws or use power tools, as this may damage the product.

Tools You May Need

*You might need a screwdriver (+/-) to complete this assembly.



Persons and Time Needed For Assembly


Box	People	Time	Difficulty
 x3	 x2	 2 hours	 3

Assembly Directions

Slides Must be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez-les de côté jusqu'au moment de l'assemblage.



Assembly Directions

Step 1


G x2



L x6




I x1



Step 2

A x20




Assembly Directions

Step 3

A x8 


N x4 



Step 4

J x2
J2 
J1 



L x8 



Assembly Directions


Step 5

B x8




Step 6

N x8




Parts 23 and 24 are auxiliary backing plates.

Step 7



Step 8


B x4



Assembly Directions

Step 9



B x4



After completing this step, stand the cabinet upright.

Step 10


B x12



Assembly Directions


Step 11

K x4 



Step 12


A x10 



Assembly Directions

Step 13


B x10 



Step 14

J x2 

L x6 



After completing this step, flip the panel 180°

Assembly Directions

Step 15


A x6



J x2





L x8



Step 16

B x6




Assembly Directions

Step 17

H x4



P x8




Step 18

J x2



L x6



After completing this step, flip the panel 180°

Assembly Directions

Step 19


A x6



J x2





L x8



Step 20

B x6




Assembly Directions

Step 21

H x4



P x8




Step 22

J x2




L x6



After completing this step, flip the panel 180°


Step 23

A x14 



Step 24




A x5 



Assembly Directions




Step 25

B x2




Step 26

B x3




Step 27

B x5



Step 28


B x2



Assembly Directions

Step 29

B x7




Step 30

H x4




P x8



Assembly Directions

Step 31


A x11



Step 32

After completing this step, flip the panel 180°

B x8




Assembly Directions

Step 33

B x3



M x4




Step 34


O x2




Q x4




Step 35



Step 36




Step 37



Step 38

N x4 




Assembly Directions

Step 39


E x3 

P x18 



After completing this step, flip the panel 180°


Step 40

G x2 

L x4 

C x2 

R x4 




Assembly Directions

Step 41


O x4 

F x8 



Step 42


N x3 



Step 43

E x2 


P x12 




Step 44

D x8 


L x64 




Step 45



Step 46




Rotate the hook of G1 to align with the lock of G2.




Assembly Directions

Step 47




Step 48




OK

Assembly Directions

Step 49




Step 50




Assembly Directions

Step 51



Step 52






Troubleshoot


Product Category	Fault	Cause Analysis	Handling Method
Wood furniture	Door opening is not flexible	The furniture is not leveled	Use items to level the furniture
		The door hinges should be adjusted properly.	Adjust door hinges and apply lubricating oil.
	Inflexible opening of drawer	Overload or deformation	Reduce weight, adjust guide rails, lubricate
	Loose component connection	Loose hinges or screws	The poke part should be coated with an appropriate amount of 502 glue, then re-install or tighten the screws.
	Minor scratches	friction with hard o sharp objects	Use a brush to apply similar pigment ink along wood grain to the scratches, then wipe off the excess.
	Corrosive stains	Accidentally stained with chemical solvents such as nail polish, nail polish remover, ect.	Wipe them with a dry cotton cloth immediately

Possible Issues During Assembly:

- The two boards can't be aligned at the same level.




- Holes on the boards and poles are not aligned, so screws can't be installed.



Recommended Solution:

- Please slightly loosen all screws and adjust the boards. Because the diameter of the holes on the pipes is 23 mm larger than that of bolts, the position of the boards can be adjusted.



- If it still doesn't work after adjustment, please contact us for more solutions.

Usage and Maintenance

Use and Care

- Leave it vacant for half a month before use, maintain good ventilation to eliminate any odor.
- Place items steadily, heavier items should be placed at the bottom to avoid tipping over. For high temperature or frozen items, please put a heat-resistant pad underneath.
- Do not directly push or drag hard objects on the furniture to avoid scratching the surface.
- Avoid prolonged exposure to sunlight or heat sources to prevent discoloration or fading.
- Pay attention to moisture prevention to avoid mold. Keep the furniture placed steadily to prevent breakage or loosening.
- Please educate children to stay away from the glass sharp corners of the furniture.
- When opening and closing doors or drawers, handle them gently and check the screws regularly to tighten them.
- Use a soft dry cloth to dust, a slightly damp cloth to clean the surface, avoid abrasive cleaners.

Help Center

Treat your furniture with care and follow the maintenance guidelines. In return, your furniture will provide you with lasting comfort and support. For any additional inquiries or assistance, please do not hesitate to contact us



Inquiry



Assembly issue



Missing parts



Returns&Refunds

We look forward to seeing you again soon.