









ASSEMBLY INSTRUCTIONS

Component List :

Hardware List :

<p>(A) Bun foot</p>  <p>4pcs</p>	<p>(B) Dresser</p>  <p>1pc</p>	<p>(C) Mirror</p>  <p>1pc</p>	<p>(D) Support rail</p>  <p>2 pc</p>	<p>① JCBC Bolt 1/4" * 28mm</p>  <p>8pcs</p>	<p>② Lock Washer 1/4" * 10mm</p>  <p>8pcs</p>	<p>③ Flat Washer 1/4" * 16mm</p>  <p>8pcs</p>	<p>④ Allen Key 1/4 "</p>  <p>1pc</p>
-------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Step 1: Install Bun Foot (A) to Dresser (B).

Step 2: Attached Support Rails (D) to the back of Dresser (B) using JCBC Bolt (1), Lock Washer (2), Flat Washer (3), tighten with Allen Key (4).

Step 3: Place Mirror (C) on the Dresser (B), align Mirror with the center of Dresser, back face the Support Rail (D).

Step 4: Secure the Mirror (C) using JCBC Bolt (1), Lock Washer (2), Flat Washer (3), tighten with Allen Key (4).

