

## Use & Care | 12' x 12' Gazebo



### Easy Set up

Please follow these safety precautions, care, and maintenance tips when using your gazebo.

*It is your responsibility to read and save these instructions before attempting to set up your gazebo.*



- Never set up or continue to use in any rain, wind, or stormy conditions, especially lightning storms.
  - ✓ Damage can occur to your gazebo and put you and others in potential danger.



- Take your time to avoid bending the frame or pinching your fingers or hands while opening and closing the frame.



- Avoid setting up your gazebo on steep inclines.
- Do not use your gazebo for permanent shelter.
  - ✓ It is designed for temporary use only.
- Always keep your gazebo away from heat and flames.
  - ✓ Do not barbeque or build fires under your gazebo.
- Never leave your gazebo unattended.
- Hand wash the gazebo using only mild soap and water.
  - ✓ Never use harsh detergents, abrasives, or bleach.
  - ✓ Do not machine wash.



### Portable

- Never fold or store your gazebo when it is wet or even damp.
  - ✓ Let it dry completely to avoid mildew.