


ASSEMBLY INSTRUCTION

ITEM NO.N715P426869

Dining Chair



ASSEMBLY INSTRUCTION

ITEM NO.N715P426869

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION

ITEM NO.N715P426869




ASSEMBLY INSTRUCTION

ITEM NO.N715P426869


Part List

(A)




BACK FRAME (2 pcs)

(B)




SEAT FRAME (2 pcs)

(C)




LEG LEFT (2 pcs)

(D)




LEG RIGHT (2 pcs)

(E)




LEFT SIDE STRETCHER (2 pcs)

(F)



RIGHT SIDE STRETCHER (2 pcs)

(G)




BETWEEN STRETCHERS (2 PCS)

ASSEMBLY INSTRUCTION

ITEM NO.N715P426869

Hardware List


①



Ø 1/4" x 40 mm

BOLT (4 pcs)


②



Ø 1/4" x 55 mm

BOLT (8 pcs)

③



Ø 1/4" x 75 mm

BOLT (8 pcs)


④



Ø5/16" x 13 mm

LOCK WASHER (20 pcs)

⑤



Ø5/16" x 19 x 2 mm

FLAT WASHER (20 pcs)


⑥



4 mm

ALLEN KEY (2 pcs)


⑦



Ø4 x 38 mm

WOOD SCREWS (12 pcs)

Tools Requires




NOT INCLUDED

ASSEMBLY INSTRUCTION


ITEM NO.N715P426869


STEP 1:



BOLT Ø 1/4" x 40 mm	BOLT Ø 1/4" x 75 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16" x 19 x 2 mm	ALLEN KEY 4 mm
				
① x 4	③ x 8	④ x 12	⑤ x 12	⑥ x 1

STEP 2:






WOOD SCREWS Ø4 x 38mm

⑦ x 4

ASSEMBLY INSTRUCTION

ITEM NO.N715P426869

STEP 3:



BOLT Ø 1/4" x 55 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16" x 19 x 2 mm	ALLEN KEY 4 mm	WOOD SCREW Ø4 x 38mm
				
② x 8	④ x 8	⑤ x 8	⑥ x 1	⑦ x 8

COMPLETE

