

175

**LIGHTING**

1. Make sure put correct battery in and Read Instructions before lighting .
2. Control knob must be in the "OFF" position.
3. Connect propane cylinder (See Manual).
4. Push and turn control knob counter clockwise to "MIN".
5. Press the igniter button repeatedly to light burner.
6. Release control knob after 45 seconds.
7. If ignition does not occur in 45 seconds, push and turn burner control knob to "OFF", wait 5 minutes, and repeat lighting procedure.
8. If igniter does not light burner, use a long match or long lighter.
9. Adjust flame to desired intensity with the control knob.


**TURNING OFF**

1. Turn and push the control knob clockwise to the "OFF" position.
2. Turn the cylinder valve on the gas tank clockwise to close.


CAUTION: The gas supply must be turned off at the LP-gas supply cylinder when this appliance is not in use.



1 AAA  
1.5V



IGNITOR



36