

TV stand




Team
Assembly
Recommended

fireplace cabinet



58" Two Door TV Stand/ Fireplace Installation Manual



Team Assembly Recommended

Trouble shooting:

Missing / Wrong / Broken parts and installation issues

↓


Send email with your question, pic and order NO.

↓

Respond within 24 hours

↓


Issue resolved




Note:Don't tighten all screws during installation.

Components



1 x1



2 x1



3 x1


4 x1


5 x1


6 x2


7 x1


8 x1


9 x1


10 x1


11 x1


12 x1



13 x1


14 x2


15 x1


16 x1



17 x1


18 x1



19 x1


20 x1








21 x1


22 x1


23 x2



24 x1


Screws & Tools

A		x63+2			
B	 Ø15 x11mm	x63+2			
C	 Ø8 x 30mm	x45+2			
D	 Ø3x20mm	x8+1			
E	 Ø3.5x14mm	x38+2			
F	 M4x50mm	x4+1			
G	 Ø3 x14mm	x38+2			
H		x12			
I		x2			
J		x2			
K		x4			
L		x2			
M		x20			
N	 Ø3.5x30mm	x4+1			


Check all the components & screws before assembly.
Do not install in case part is missing, contact us to get.
We will resend within 24 hours.


Step 1






Step 2







Step 3




Step 4





Step 5







Step 6







Step 7






Step 8






Step 9



A
4PCS


Step 10




B
4PCS

C
4PCS


Step 11




Step 12




Step 13




Step 14




Step 15




Step 16




Step 17




Step 18





Step 19






The door stop（I） protrudes by 2 to 3 millimeters.






NOTE: Press and release, and door will spring open.


Step 20




Step 21



Step 22



Step 23





If you intended to use this product as a TV stand, continue the assembly instruction on page 14.

If you intended to use this product as a fireplace mantel, continue the assembly instruction on page 17.


TV STAND ASSEMBLY

Step 20







Step 21



Step 22




Step 23



Step 24


NOTE: Install according to the stove manual(30" Insert Fireplace Heater)



Carefully set the unit from the back of the mantel and center it in the opening.


Check the alignment and attach the unit to the mantel by inserting screws through the drilled holes on the trim to the mantel.

NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.



Step 25

Finally, you got a 58" Two Door TV Stand/ Fireplace!



IMPORTANT SAFETY INFORMATION

Please carefully read the instructions and caution warnings below before assembling the product. Following this guide will ensure that you install, use and maintain the product properly.

- Please keep this installation and user manual/instructions for future reference in case you need to assemble the product.
- Do not assemble if you notice serious damage such as cracks or bends.
- During installation, please use work gloves for hand safety.
- Please assemble the unit on carpeted floor or the flat cardboard box to avoid scratching the surface or your floor while assembling on the floor.
- To assemble, please use the complimentary installation tools (Allen Wrench). Pay more attention to the direction of components at each steps.
- It is recommended that two people work together to assemble the product.
- Please do not tighten the screws up too much, just to 80% before you finish to make the installion go on successfully.

RETURN POLICY

We believe you will absolutely love your new product. But for some reason you want to return your item, please contact us within 30 days after receiving and ensure that the product which you want to return is in a good condition in the original box with all original certificates of purchase, manuals and accessories attached.

HOW TO MAINTAIN YOUR PRODUCT:

- Check the screws of the product are not loose from regular use.
- Do not use sharp instruments, rubbing alcohol, corrosive chemicals, or abrasive cleaners to clean the product.
- Do not keep the product in a damp environment for a long period of time. The damp environment may cause the iron components to rust and the plates to bulge and crack.