


PLEASE NOTE: Check if you received all components before opening the plastic bag. Damaging it results in rejection of any possible claims

SWIVEL OFFICE CHAIR



Chair assembly instruction:

1. Put the armrest to the seat plate using the screws.
2. Place the pneumatic lift with a cover into the mechanism.
3. Put 5 castors to the 5-star base.
4. Insert the seat plate with the pneumatic lift into the 5-star base cone shaped slot.
5. Put the connector bar of the backrest into the cover of the mechanism.

Operations:

1. Use the seat height handle to adjust the height.
2. Use the back tilt to adjust the position of the backrest.

Attention:

1. Pneumatic lift warming and disassembly strictly forbidden.
2. Max load 115 kg
3. This chair intended only for sitting any other use voids the warranty.
4. Avoid humidity.
5. Keep away from the source of heat.
6. Tighten all screws again after 30 day of.

The list of parts in the plastic bag:

1. gas lift 2. gas lift cover 3. the set of castors 4. mounting screws 5. Mechanism cover

