

Assembly Instructions for SIDE CHAIR








Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST

No.	PART DESC.	Q'TY
A	Pub Side Chair Back Frame	1
B	Pub Side Chair Seat Frame With Cushion	1
C	Pub Side Chair Left / Right Front Leg	1 SET
D	Pub Side Chair Front Side Stretcher	1
E	Pub Side Chair LSF / RSF Side Stretcher	1 SET

HARDWARE LIST

No.		HARDWARE DESC	Q'TY
1		Long bolt (1/4" x 85mm)	4
2		Bolt (1/4" x 60mm)	4
3		Short bolt (1/4" x 40mm)	2
4		Spring washer (1/4")	10
5		Flat washer (1/4")	10
6		Screw (#4 x 38mm)	6
7		Allen key	1

STEP:1



STEP:2

