

USER MANUAL

12 Inch Silent Voice Sensor LED Night Light Wall Clock

INSTRUCTION:


Please read these instructions carefully and keep them on file for future reference.

ACTIVATING THE CLOCK:

Insert 1 x AA battery into the clock movement battery compartment, taking care to observe the polarity.

SETTING THE TIME:

To set the time, rotate the "TIME SET KNOB" until the correct time is reached;



ACTIVATING THE LIGHTING:


1. Open the battery compartment cover, insert 4 x AA batteries into the battery compartment, taking care to observe the polarity. Then close the battery compartment cover.
2. Toggle the button of the light to the **ON** state.

3. There are 2 switches buttons on the back of the clock to set up the light of the clock:

- ① The **ON** mode is to turn on the light.
- ② The **OFF** mode is to turn off the light and the light won't light up.

Note:

When the light button is "**ON**", It will be automatically lighted up by the sound-controlled and light-controlled sensor. But the surrounding environment needs to be dark. It will last 45 seconds, and won't affect your sleep.



NOTE:

Although any AA dry battery can power the clock movement, a carbon-zinc battery is recommended for reliable performance. LED sensor light recommend use dry battery not carbon-zinc battery for reliable performance.

FAQ:

The light of the clock does not work properly, please follow the steps below to test:

1. Please check the switch is turned to "ON".
2. Use the new batteries, and the "+" and "-" terminals aligned properly.
3. In a dark environment and make a sound

If still have problem, please feel free to contact OCEST customer service team.

WHEN HANGING THE CLOCK PLEASE NOTE THE FOLLOWING

Caution - Before drilling any holes in walls or other surfaces, check the location of any piping or electrical cabling.

1. Ensure you check the wall and hanging hook or screw is appropriate for the weight of the product.
2. To hang the clock, insert the hanging hook or screw into the hanging hole at the back of the clock or hang the clock on the hook/screw from the rim of the case.
3. If in doubt consult a professional trader person.

CHANGING THE BATTERY:

It is recommended that you replace the battery annually even if the clock is still running. Try to use ordinary 1 X AA (1.5V) battery to the movement.

It is recommended that you replace the batteries when the lights of clock are dim for proper operation. Remove the battery if the clock is stored or not in use. Remove the exhausted battery from the product.

Warning: Do not recharge non-rechargeable batteries.

Please dispose of the used battery in a responsible manner. For more information please contact your local authority.

MAINTENANCE:

A soft cloth may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock.



MADE IN CHINA