


ASSEMBLY INSTRUCTIONS

SKU/ITEM# 529 Dining Chair

meridian.
furniture



+ Parts Included

① LEG (1 pc)



② SEAT (1 pc)



+ Do Not Use Power Tools



+ Suggested Adults



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # ① - LEG
Part # ② - SEAT

Do not assemble if any of the following Hardware parts are missing:

- Part # **A** - Bolt
Part # **B** - FLAT WASHER
Part # **C** - Allen Key

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Hardware Included

A SCREW (4 pcs)



B FLAT WASHER (4 pcs)





C ALLEN (1 pc)



ASSEMBLY INSTRUCTIONS

SKU/ITEM# 529 Dining Chair

meridian.
furniture



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

www.MeridianFurnitureUSA.com | support@meridianfurnitureusa.com