






Unpacking & Arranging Your Brand New Artificial Christmas Tree

Congratulations on purchasing your brand new Artificial Christmas Tree
Keep this instructional pamphlet as a how-to guide on setting up and fluffing your holiday star.



To Start

- Ensure that all parts have been delivered
- Save the delivery box for storing and keeping your new artificial Christmas tree safe.

	Top	Middle	Base	Base	Power Source For Pre-lit Trees ONLY
Trees with 3 sections					
Trees with 2 sections					

Assembling Instructions

- 1** Assemble the stand **(D)** on a flat surface; unfold all the legs and insert the screws into each of the openings to keep your tree safely stabilized.



- 2** Start by inserting the base of the tree **(C)** into the stabilized stand **(D)**; proceed by inserting sections **(B)** and **(A)** respectively.



Trees will be built according to two variations



3 Make sure all sections are secure for lights.
You can connect the plug into the power outlet to make sure all sections are properly connected; unplug after.



4 Starting at the bottom, bend and unfold branches, one-by-one.



5 Make final trimmings by turning tree and ensuring all branches look lifelike.



6 Connect the plug **(E)** into a power outlet to complete the look and begin decorating!



Disassembling Your Tree

- Carefully take out all the decorations throughout your holiday tree; Save the delivery box for storing and keeping your new artificial Christmas tree safe.
- Dismantle the tree by starting at the top **(A)** and working down **(B)** through **(C)** until you reach **(D)**;
- For longer preservation, use your original shipping box to store in a cool, dry place.

 For indoor use only

 Keep away from high temperatures, fires, and open flames

 To be assembled by an adult or under parental supervision

*Illustrations are for reference only as models will have slight variation