

ASSEMBLY INSTRUCTIONS

NOTE:

Before assembling your new lamp, please read the following precautions and instructions thoroughly.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet one way only. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.

The electrical wire is connected continuously through the poles, Do not pull wires during unpacking, bad connections may result.

Place the lamp indoor dry area only. The lamp produces very high temperature, always unplug electrical cord and allow sufficient time for bulb to cool down before replacing bulb.

1. Carefully unpack all parts from the packaging and place them on a flat/smooth surface. Be sure to remove all the packaging materials from the lamp.
* Do not plug into the electrical outlet when installing or replacing bulb.
2. Tighten the **Bottom Pole** onto the **Base** until tight.
3. Tighten the **Middle Pole** onto the **Bottom Pole** until tight. then tighten the **Upper Pole** onto the **Middle pole** until tight
4. Tighten the **Neck** onto the **Upper Pole** until tight.
5. Place the **Harp** into the **Harp Socket**.
6. Place the **Shade** onto the top of the **Harp**, and tighten it with the **Finial Cap**.
7. Place the **light bulb** (not included) into the **bulb socket**.
8. Insert the plug into the wall outlet, you are ready to use

Please Note:

This lamp has a 3- way switch, for this lamp to work properly, please use only 3- way bulb.

