



# Assembly Instructions








SOFA



CHAIR

REQUIRED TOOLS: (Not included) Screw driver

PARTS:(Included)



| LABEL     | DESCRIPTION    | PICTURE   | QTY       |           |
|-----------|----------------|---|-----------|-----------|
|           |                |   | SOFA      | CHAIR     |
| <b>A1</b> | SOFA ASSEMBLY  |   | <b>1</b>  |           |
| <b>A2</b> | CHAIR ASSEMBLY |  |           | <b>1</b>  |
| <b>B</b>  | WOOD LEG       |  | <b>4</b>  | <b>4</b>  |
| <b>C</b>  | SUPPORT LEG    |  | <b>1</b>  |           |
| <b>D</b>  | PLASTIC WASHER |  | <b>12</b> | <b>12</b> |

# Assembly Instructions

It is recommended to have 2 adults on hand for assembly.

Ensure that all bolts are tightened before use. Check and tighten all bolts periodically throughout use of the products.

## ( SOFA )



## ( CHAIR )

