










## CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.  
The use of steam or water-based cleaners may cause excessive shrinking or staining.

## NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

### Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Chassis		1X
C	Caster		5X
D	Air Bolt Pole		1X
E	Lever Mechanism		1X
HW1	Split Lock Washer(M6)		4X
HW2	Flat Washer(M6)		4X
HW3	Socket Screws 6 *1.05*30MM		4X
HW4	Allen Key		1X

**Dimensions:25.39"\*25.39"\*33.86"~36.81"**

**Weight Capacity: 275 lbs**



**WARNING: DO NOT STAND ON CHAIR**

**WARNING: DO NOT OVER TORQUE BOLTS/SCREWS**







**The base and hardware are located under the chair**

## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen key

		
<p><b>STEP1</b> OPEN THE CARTON BOX AND REMOVE THE SEAT BODY, PARTS AND HARDWARE PACK.</p>	<p><b>STEP2</b> ATTACH THE FIVE CASTER C TO THE CHASSIS B AS SHOWN.</p>	<p><b>STEP3</b> PUT THE WASHERS ON THE BOLT IN THE ORDER SHOWN IN THE PICTURE</p>
		
<p><b>STEP4</b> CONNECT THE LEVER MECHANISM E WITH SEAT BODY A AS SHOWN.</p>	<p><b>STEP5</b> CONNECT THE SEAT BODY A AND THE ASSEMBLED BASE B WITH THE AIR BOLT POLE D AS SHOWN.</p>	<p><b>STEP6</b> FINISHED.</p>
<p style="text-align: center;"><b>The base and hardware are located under the chair</b></p>		