


ASSEMBLY INSTRUCTIONS



1. Thank you for choosing **our products.**

2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly depending on product size



- Do not assemble directly on flooring or carpet



- Assemble on a clean non-marring surface (example: packing foam)



- Save all packaging until finished

3. Assembly Notice:

- ☒ If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the

parts of the product stored in a safe place and contact us immediately so we may assist you further.

- ☒ Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the hardware spill in the box.
- ☒ Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- ☒ **IMPORTANT:** When setting up your product, **DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING.** Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- ☒ When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.


















Care & Maintenance

- 🚫  • Do not put hot items directly on furniture surface
- 🚫  • Do not clean furniture with harsh cleansers or polish
- 🚫  • Children should not climb or jump on the furniture
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth

















Caution

- This product contains small components. Please ensure that they are kept away from small children.










Parts List (US887403NW0A)








1		1		2		1
3		1		5		1
4		1		28		1
27		1		6		1
13		1		12		1
11		1		41		1
42		1		38		1
37		1		40		1
 Hardware kit						



Parts List (US887403NW0B)

7		1		8		2
9		1		10		2
14		1		15		1
16		1		17		1
18		1		19		1
20		1		21		1
22		1		23		1
24		1		25		1
26		2		29		1



Hardwares List

A		B	 15*9.5	C	 6*30
26+2 PCS		26+2 PCS		38+5PCS	
D	 5*40	E1	 3*8	E2	 3*14
136+5PCS		9+2 PCS		9+2 PCS	
F	 F1  F2  F3	G	 4*18	H	
1 SET		6+2 PCS		1 PC	
I1	 3.5*12	I2		J	 400MM
62+5 PCS		2+3 PCS		1 SET	
K	 500MM	L		M	
1 SET		4 PCS		4 PCS	
N	 3.5*14	O		P1	
24+2 PCS		16+2 PCS		2 PCS	
P2		Q		R	
2 PCS		3 PCS		2 PCS	

S		T			
2 PCS		2 PCS		2 SETS	
V		W		X	
36 PCS		14 PCS		1 PC	
Y		Z1		Z2	
1 PC		4+1 PCS		1 PC	
Z3					
1 PC					





1




C		D	
2 PCS		5 PCS	

2




C		D	
2 PCS		3 PCS	

3




D
4 PCS

4




A 2 PCS	B 2 PCS	C 2 PCS
------------	------------	------------

5





C		D	
	4 PCS		12 PCS

6





7




C		D	
	2 PCS		9 PCS

8





D	
	4 PCS



9





10




C		D	
6 PCS		17 PCS	




13



14




15




A		B	
	6 PCS		6 PCS

16




G		I1		J		M	
	1 PC		6 PCS		1 SET		1 PC

17





18





A	B	C
		
8 PCS	8 PCS	1 PC

19





C	D
	
1 PC	2 PCS

20





C	D
	
1 PC	2 PCS

21




C	D
	
1 PC	2 PCS


22





C	D
	
2 PCS	3 PCS





A	B	D
		
2 PCS	2 PCS	9 PCS





C	D
	
6 PCS	28 PCS




C	D
	
6 PCS	28 PCS




I1	K	N
		
6 PCS	1 SET	16 PCS
O	P1	P2
		
16 PCS	2 PCS	2 PCS






E1		F	 	G		I1	
	9 PCS	F2	F3 1 SET		3 PCS		8 PCS
M		Q		R		S	
	3 PCS		3 PCS		2 PCS		2 PCS




I1	
	16 PCS




Adjust the doors if needed

- Sideways adjustment
Loosen and tighten screw shown, to move doors left or right as required




- Height Adjustment
Loosen screws at B1 & B2 and move door up or down as required. Retighten Screws at B1 & B2.






●Forward and Back adjustment.
Loosen screw shown and move door in or out as required.
Retighten Screw.




E2	F	Q
		
9 PCS	1 SET	3 PCS

33




34




N	T
 4 PCS	 2 PCS

35




H 1 PC	M 4 PCS	N 4 PCS	U1 1 PC	U2 1 PC	U3 3.5*14 1 PC	U4 3.5*35 1 PC	U5 6*30 1 PC
-----------	------------	------------	------------	------------	----------------------	----------------------	--------------------

36




V
36 PCS

37




I1		14 PCS	W		14 PCS
----	---	--------	---	---	--------

38



I2		2 PCS	X		1 PC
----	---	-------	---	---	------



Please remove the backing paper from the back of Part-Z1 and stick them at the sharp positions in the diagram to prevent kids from getting injured.

U1	U2	U3	U4	U5	Y	Z1
1 PC	1 PC	3.5*14 1 PC	3.5*35 1 PC	6*30 1 PC	1 PC	4 PCS