














ASSEMBLY INSTRUCTION

SKU:W370P170343

SKU:W370P170344



Ax1 	Bx1 	Cx1 
Dx1 	Ex8 	Fx3 
Gx1 	Hx1 	Ix1 
Jx12 	Kx1 	Lx1 