NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help.

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 45 minutes.
- * Tools Required for Assembly (included): Allen Key, Key

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use. Remove wooden furniture from standing water. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge. Do not use bleach solutions

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
Α	Right Bench 3S Frame		1X
В	Left Bench 3S Frame		1X
С	Bench 2S Frame		1X
D	Glass Top	E.	1X
Е	Table Frame		1X
F	Support Leg		2X
G	Bench Leg	ß	13X
CSH1	Back Cushion 1		5X
CSH2	Back Cushion 2		1X
CSH3	Right Seat Cushion		1X
CSH4	Left Seat Cushion		1X
CSH5	Corner Seat Cushion		1X
HW1	Allen Bolt: M6 x 0.5 x 20 mm	0	34X
HW2	Allen Bolt: M6 x 0.5 x 45 mm	()) 1	2X
HW3	Allen Bolt: M6 x 0.5 x 60 mm	0	1X
HW4	Flat Washer: M6 x 1 mm	0	41X

tanding efore

Product Dimensions

OUTDOOR

24.41"W x 24.41"D x 15.75"H (Table)

50.78"W x 28.35"D x 26.38"H (Bench 2)

77.56"W x 28.35"D x 26.38"H (Bench 3)

Weight Capacity : 176 lbs (Table) : 704 lbs (Bench 2S)

: 880 lbs (Bench 3S)

Warning : Do not stand on Table/Bench Warning : Do not over torque bolts/screws

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
HW5	Plastic Cover	Ô	1X
HW6	Nut M6	۵	4X
HW7	Allen Key		2X
HW8	Кеу	5	1X



NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help.

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 5 minutes.
- * Tools Required for Assembly (included):

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use. Remove wooden furniture from standing water. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge. Do not use bleach solutions

OUTDOOR

Product Dimensions 24.41"W x 24.41"D x 15.75"H (Table)



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
D	Glass Top		1X
E	Table Frame		1X
CSH1	Back Cushion 1		3X
CSH2	Back Cushion 2		1X



Weight Capacity : 176 lbs (Table) Warning : Do not stand on Table Warning : Do not over torque bolts/screws

PREPARATION

* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

* If any part is missing or damaged, do not attempt to assemble the product.

- * Estimated Assembly Time: 5 minutes.
- * Tools Required for Assembly (included):

* If you are having difficulty, our friendly Customer Care team is always here to help.

