ASSEMBLY INSTRUCTIONS

MODEL# : F1927 DINING CHAIR

KEEP THIS DOCUMENT FOR REFERENCE IN CASE PARTS ARE NEEDED
DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED !

No.	DESCRIPTION	Q'TY
A	CHAIR BACK	2pcs
B	CHAIR SEAT	2pcs
C	CHAIR FRONT LEG	4pcs

No.	DESCRIPTION		Q'TY
1	BOLT	1/4"*80MM	8pcs
2	BOLT	1/4"*60MM	8pcs
3	BOLT	1/4"*38MM	4pcs
4	SPRING WASHER	1/4"	20pcs
5	FLAT WASHER	1/4"	20pcs
6	ALLEN KEY	M4	1pc

STEP 1



STEP 2



STEP 3



STEP 4