










Assembly Instructions

Caution: You must read this before you proceed.


Care & Maintenance

- ⊘  ● Not for commercial use. For residential use only.
 - ⊘  ● Do not put hot items directly on furniture surface.
 - ⊘  ● Do not clean furniture with harsh cleansers or polish.
 - ✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 - ⊘  ● Children should not climb or jump on the furniture.
 - ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
 - ✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 - ⊘  ● Stains may be removed with mild soap solution and damp cloth.
-
- ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.



Crane




Parts List

| Label | Picture | Description | QTY |
|-------|---|-------------|-----|
| A |  | Crane | 1 |

Hardware


| Label | Picture | Description | QTY |
|-------|---|-----------------------|-----|
| ① |  | Stake | 2 |
| ② |  | Hammer (not provided) | 1 |

Step 1



Unpack and place all parts on a clean soft surface.

Step 2



Affix the Crane(A) to the ground by inserting the Stake(①) through the mounting position with Hammer(②).

Step 3



Your crane is ready for use.