

Assembly Instructions

CAUTION: You must read these Assembly Instructions before you proceed.

Care & Maintenance



- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.




- Stains may be removed with mild soap solution and damp cloth.






- Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Please look in Seat Panel for hardware packs



DOUBLE CHAISE



Parts List:


Label	Picture	Description	Qty
A		Seat Panel	1
B		Leg Panel	2
C		Middle Leg Panel	1

Hardware:

Label	Picture	Description	Qty
①		Allen Wrench	2
②		Bolt (M6x45mm)	13

Assembly Preparation:

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Step:

OVERVIEW




This Double Chaise has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Double Chaise, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.


Step 2



With assistance from your adult partner, place Seat Panel (A) facing down on a clean, non-marring surface then attach Middle Leg Panel (C) to Seat Panel (A) by using Bolts (②) with Allen Wrench (①) as shown above.

DO NOT fully tighten the Bolts.


Step 3



With assistance from your adult partner, attach Leg Panels (B) to Seat Panel (A) of the assembled part in Step 2 then secure by using Bolts (②) with Allen Wrench (①) as shown above.

DO NOT fully tighten the Bolts.

Step 4



Inspect it and make sure all parts are adequately connected.
With assistance from your adult partner, stand the Double Chaise up.
Gently and gracefully, sit onto the Double Chaise.
This will help to align all the parts at all joint areas.
Then get off the Double Chaise and proceed to tighten the Bolts in a sequential manner.
When tightening the Bolts tighten sequentially.
DO NOT tighten any Bolts fully and then move on towards the next one.
If there are still wobbles, loosen the Bolts execute this same process.
WARNING!! IF DOUBLE CHAISE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.
Your Double Chaise is ready for use.
This Double Chaise can only be used on a flat, level surface.
Note: Align the Backrest of Chaise Lounge in position you want as shown above.