

Disassembly and Storage

Remove all decorations.
Disassemble the tree in reverse order of assembly.
Suggest to store the tree in its original carton box or in storage bag and keep in a cool dry place.

Caution

To be assembled by or under the supervision of an adult.
Keep plastic bags out of reach of children.
Keep away from fire or hot temperatures. Do not light a candle on or near the tree. Do not leave lighted electric cords unattended.
Do not overload with heavy ornaments and/or too many decorations.
Place the tree on an even surface to ensure stability.
This tree is intended for indoor use only.
Keep this information for future reference.

Assembly Instruction

7.5ft Silver Tinsel Artificial Christmas Tree



Carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, safe surface. If you require assistance with assembly or parts, please call t





Before Assembling

1. Please check and make sure all the parts have been received.
2. Tools are not required for assembly.
3. The length of extension cord is 59 inch, please set up the tree in the suitable place away from the power socket.

Content:


Reference No.	Height	Number of tree parts	Stand
2004900025	7.5'	3	Metal

Part List:


Code	A	B	C	D
Part				
Description	Tree Top	Upper part	Lower Part	Stand & 3 Screws
QTY/PC	1	1	1	1

Assembly Instructions


- Step 1** Assemble the stand on a stable surface.
 Unfold the stand and insert the screws as indicated on Figure 1.



- Step 2** Insert the trunk in the stand as indicated on Figure 2
 When the trunk consists of more than one part, begin by inserting into the stand (Part D) the lower parts of the tree (Part C, Part B) in respective order, ending with the top (Part A).



- Step 3** Unfold the branches one-by-one beginning with the lowest.



- Step 4** Make final adjustment for an elegant look.

