

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.




- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

RECLINER



Parts List


Label	Picture	Description	QTY
A		Chair Backrest	1
B1		Right Wing	1
B2		Left Wing	1
C		Chair Base	1
D		Front Leg	2
E		Hind Leg	2

Hardware

Label	Picture	Description	QTY
①		Wrench(M6)	1
②		Washer(1/4)	3
③		Washer Ring	3
④		Bolt(1/4*20mm)	3

Assembly Preparation

Before
Beginning
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-






- Save all packaging until finished-




Assembly Steps



Overview




This Recliner has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Recliner parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1	 The diagram shows a list of hardware: three washers (X3), three screws (X3), three cam bolts (X3), and one Allen key (X1). Below the list are four leg caps. To the right, a line drawing of the chair base (C) is shown with the inner box open, indicated by an arrow.
Position the Chair Base(C) on its back, as shown.(Perferrably on a surface that won't scratch the upholstery.) Open the inner box and take out the 4 Legs and hardware provided, as picture shown on above.	
Step 2	 The diagram shows the chair base (C) with the inner box open. An arrow points to the right, showing the inner box being removed. To the right, the right wing (B1) and left wing (B2) are shown, along with the footrest.
Then,turn the Chair Base(C) upside down on a clean,non-marring surface. Extend the Footrest to open. Carefully take out inner box stowed as shown above. Open it and you will find Right Wings (B1) & Left Wing(B2). Stow the Footrest to original position.	
Step 3	 The diagram shows the chair base (C) upside down. A circular inset shows a close-up of the front leg (D) being attached to the chair base (C) using a plastic washer. The leg is turned clockwise to secure it.
Position the Chair Base(C) on its back , as shown above. Attach the Front Leg(D) to Chair Base(C) with plastic washer on the Leg(D) by turning the legs clockwise as shown.	

<u>Step 4</u>	
Install the Front Leg(D) and the Hind Leg(E) to the Chair base (C) by rotating the legs clockwise as illustrated. This aligns with the bolt positions.	
<u>Step 5</u>	
Attach the Hind Leg(E) to Chair Base(C) use Bolt(④) ,Washer Ring(③),Washer(②) with Wrench(①) by turning the legs clockwise as shown.	
<u>Step 6</u>	
Place the backrest (A) upright. Align the left wing (B2) with the left side of the backrest (A). Then, slide the left wing (B2) forward with your hand to ensure it fits into place as shown in the image. Do the same with the right wing (B1).	

<u>Step 7</u>	
With assistance from your adult partner,hold up the fully assembled backrest with Wings,stand behind the chair. Insert the small metal arms on the sides of the Chair Backrest into the prefabricated slide lock gadget on the Chair Base as shown above. Firmly but gently,push the Chair Backrest downwards until the Backrest is fully slotted and locked into position.	
<u>Step 8</u>	
Smooth down the fabric flap on the Chair Backrest. Run your hands down both sides of the flap, from top to bottom, allowing the magic tape to adhere to the flap under the seat of the chair.Your Recliner is ready for use.	
<u>Step 9</u>	
Make sure all parts are connected and securely locked into position. Your Recliner is ready for use. This Recliner can only be used on a flat, level surface.	


Disassembly



Disassembly Note: Open the flap on the Chair Backrest(A), use a screwdriver (Don't use fingers) pressing outward on the metal ear on the pre-attached Metal Bracket on one side of the Chair Backrest(B).

With assistance of you adult partner to keep the Chair Base(B) in place, pull out the Chair Backrest(A) upward at the same time, repeat the same step for another side.

Then the Chair Backrest(A) can be taken out.

User Instructions.	
Recliner Chair	
Please read the Instruction Manual below carefully before use.	
This is a Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.	
Supervise children, when in use of this Recliner.	
 WARNING  Correct Way to Use ✓  Incorrect Way to Use ✗  Incorrect Way to Use ✗  Incorrect Way to Use ✗  Incorrect Way to Use ✗  Incorrect Way to Use ✗	
Always leave the chair in an upright and closed position after use. Keep hands and feet clear of the footrest mechanism and any gaps. Do not allow children to play on the chair. Do not lean to side to pick up anything while sitting on the chair. Do not sit on the arms. Do not stand up when the recliner open. Only the occupant should operate the chair.	
To get into a reclined posture - To Recline backrest	
Sit into the seat. Place your feet apart . Place your left and right arm onto the armrest. Synchronise a backward push with your arms. Use your body weight and push backwards into the seat into a fully reclined position.	
	
To get out of chair - move Seatback into Upright Position	
Tilt your body weight slightly forward and upwards. The seat back will come up to an upright position. Where necessary, use either your arms help lift- push yourself out of the seat.	
